

Spare Parts
Price List
April 2017

warmth

<u>Spares Stockists Nationwide</u>	3
<u>Technical Support</u>	3
<u>Training</u>	3
<u>Customer Services</u>	3
<u>Spare Parts</u>	4-30

Spares Stockists Nationwide

Spare parts for all Vokèra products are available through our nationwide network of approved spares stockists. For peace of mind, spares availability is guaranteed for 10 years after product withdrawal. Our large spares stockist network supports repairs and maintenance of Vokèra boilers.

Visit www.vokera.co.uk to view a list of our approved spares stockists.

Important: Fitting any of the parts listed should only be undertaken by a compliant Gas Safe Registered engineer.

Technical Support

Our fully trained Gas Safe Registered technical team provides technical advice to help select the correct spare part for any particular Vokèra boiler. Call **0844 391 0999** (option 4)

Alternatively you can view spare parts within each individual product installation manual at www.vokera.co.uk

Training

A major factor in the success of Vokèra is a passionate commitment to professional standards within the domestic heating industry. Our industry leading Technical Training programme embodies that commitment and provides the most comprehensive training syllabus for domestic heating professionals in the UK today. Vokèra installers enjoy full support for their training requirements and we are happy to adapt our resources to your

specific needs for individual or group training courses. Our nationwide network of training centres and external facilities means that you are never too far away from a Vokèra training resource anywhere in England, Wales or Scotland.

For further information or to book a Vokèra training course, please call **0844 391 0999** (option 5) or visit www.vokera.co.uk

Customer Services

If you ever have a problem or a question relating to a Vokèra product, please call us on **0844 391 0999** (option 2).

Customer Care Centre operates:
08.15am - 17.00pm Monday to Friday
08.00am - 12.00pm Saturday



SPARE PARTS

Part No.	Description	Price
01005043	Obsolete - Modulator Kit	45.10
01005067	LPG To NG Conversion Kit	5.93
01005080	Test Component	44.08
01005085	Obsolete - Frame	80.10
01005088	LPG To NG Conversion Kit	16.31
01005090	NG To LPG Conversion Kit	16.31
01005127	3 Way Valve Overhaul Kit	8.33
01005133	Frame Assembly	70.09
01005134	Obsolete - Frame Assembly	70.68
01005135	Obsolete - Frame Assembly	86.97
01005137	Venting Plugs Kit	8.15
01005138	Frame	107.70
01005177	Microswitch Kit Rep 8468 & 8447	21.36
01005178	Microswitch rep 0182/0809/0811	19.58
01005180	Conversion Kit LPG to NG	8.90
01005181	Obsolete - Conversion Kit	14.08
01005182	Conversion Kit to NG	8.90
01005183	Obsolete - Conversion Kit	14.08
01005193	NG to LPG Conversion Kit	17.79
01005195	LPG to NG Conversion Kit	13.81
01005217	LPG Conversion Kit	35.69
01005225	Conversion Kit LPG to NG	16.46
01005234	Glass Kit	6.46
01005242	Spark Electrode Kit	42.82
01005243	Frame Assembly	89.00
01005245	Exchanger in place of 1841 & 2381	189.85
01005246	Main Heat Exchanger rep 2378 & 1914 Engineers and Agents Only Main Heat Exchanger in place 5388 & 10021231	207.65
01005247	Engineer/Agents 7810 & 10021232	126.79
01005248	Engineer/Agents 7810 & 10021232	148.84
01005259	Frame Assembly	78.28
01005272	Air Pressure Switch Rep 7070/8195/9232	49.13
01005284	Conversion Kit to NG	16.46
01005285	NG to LPG Conversion Kit	14.82
01005286	LPG to NG Conversion Kit	20.31
01005291	Condensing Unit	410.45
01005292	Connections Kit	25.63
01005293	Venturi press tube Kit	18.09
01005294	Frame	121.08
01005297	NG to LPG CConversion Kit	41.27
01005303	NG to LPG Conversion Kit	15.88
01005306	Knob support & gear wheel Kit	9.23
01005323	Casing	118.77
01005348	Obsolete - Anti condense Kit	-
01005362	Silicone tube Kit	14.76
01005365	Frame Assembly	117.98
01005366	Condensing exchanger Assembly	356.57
01005369	Condensing exchanger Assembly	382.04
01005389	NG to LPG Conversion Kit (4.7 jet)	9.57
01005390	Use 01005448	9.57
01005403	Frame	64.68
01005404	Use 10027599	-
01005405	Use 20030209 for Venturi and 10027538 for Pito pipe	20.27
01005407	NG to LPG Conversion Kit	18.57
01005409	NG to LPG Conversion Kit	18.28
01005411	Condensing unit	392.33
01005415	Frame	67.65
01005441	Frame Assembly	105.00
01005442	Hinge Assembly	4.92
01005443	Condensing exchanger Assembly	484.55
01005444	Frame Assembly	50.40
01005445	Frame Assembly	77.98
01005446	NG to LPG Conversion Kit (3.6)	15.51
01005447	NG to LPG Conversion Kit (4.7)	14.71
01005448	NG to LPG Conversion Kit (5.0 jet) Replaced 01005390	14.71
01005458	USE 10028537	81.77
01005464	LPG to NG Conversion Kit	7.58
01005465	LPG to NG Conversion Kit (6.7)	9.03
01005466	LPG to NG Conversion Kit (7.0 Jet)	9.03
01005468	Wiring box	15.42

SPARE PARTS

Part No.	Description	Price
01005469	Clips for anti frost resistors	23.45
01005481	Casing	65.43
01005482	Casing	65.43
01005497	Casing	71.20
01005500	NG to LPG Conversion Kit	9.96
0112	Obsolete - Pressure limiting valve	-
0113	Screw	0.37
0114	Obsolete - Screw	-
0117	Obsolete - Fan Spring	-
0119	Obsolete	-
0139	3 Way Valve Tail Plate	19.68
0159	3 Way Valve Head Shaft	28.26
0182	Use 01005178	-
0184	Extension Shaft	28.26
020	Silicone Grease	13.46
021	Obsolete - Threeway valve key	-
0213	Obsolete - Conversion Kit LPG	-
0215	Obsolete - Conversion Kit LPG	-
0216	Front Seal	4.13
0218	Retaining Ring	4.91
0219	Shuttle	16.18
0220	Obsolete - Screw	-
0221	Washer	0.79
0225	Obsolete - Eclipse Fan Adapter	-
0226	Diaphragm (6 Screw)	6.12
0292	Obsolete	-
029370	Use 029620	-
029373	Casing (Right Side)	56.76
029374	Casing (Left Side)	56.76
029375	Casing (Front)	54.42
029376	Fixing Plate	41.55
0296	Obsolete	-
029620	Casing (Top)	55.94
0298	Obsolete - 0.75 jet	-
0301	Obsolete - Nylon Plate	-
0309	Front Seal	11.30
03165	Thermal Store	375.75
0338	Obsolete	-
0340	Obsolete	-
0341	Fibre Washer	1.73
0349	O Ring	0.32
0352	Obsolete	-
0353	Obsolete - O Ring	-
0357	Obsolete - NG Jets 125	-
0358	Obsolete - LPG Jets 072	-
0360	Obsolete - Combustion Chamber Metal Case	-
0361	Obsolete - Insulation Panels	-
0363	Obsolete - Insulation Panels For Chamber	-
0364	Obsolete - By pass plug	-
0365	Obsolete - By pass spring	-
0366	Obsolete - Filter (Cold Water Inlet)	-
0367	Obsolete - Flow Regulator	-
0371	Washer	1.25
0373	Obsolete - O Ring	-
0378	Obsolete - Water Flow Regulating Screw	-
0379	Obsolete - By pass plug	-
0380	Obsolete - By pass plug & spring	-
0381	Venturi	2.34
0382	Obsolete - Insulation Panels for chamber	-
0394	NG Spring	1.91
0395	Obsolete - Aluminum Spring	-
0401	Obsolete - Gas Valve Solenoid	-
0402	Obsolete - Gas Valve Solenoid	-
0407	Obsolete - Pipe	-
04213	Use 04227 Insulation panel	-
04223	Use 04227	-
04227	Insulation Cover	13.66
0439	Auto Air Vent	9.89
0442	Air Box Clip	4.37

SPARE PARTS

Part No.	Description	Price
0444	Obsolete - Instrument Panel	-
0445	Obsolete - Instrument Panel	-
0533	Obsolete	-
0536	Nylon Plate	9.04
05420	Obsolete - Bracket	-
05422	Obsolete - Clip (R102906)	-
0549	Obsolete - Auto. By-Pass Retaining Cap	-
0550	Obsolete - Spring for Gas Valve	-
0552	Obsolete - Spring For Auto. By-Pass (Large)	-
0554	O Ring	0.37
0555	Spring	0.95
0556	By-pass Bearer Plate	3.65
0557	Diaphragm	5.05
05589	Bar	16.54
0563	Obsolete - Gas Valve Operator	-
05660	Bracket	12.14
05800	Obsolete - Bracket (R102918)	-
05801	Elbow (102921)	17.05
05802	Elbow	15.71
05803	Tube	17.55
05808	Clip	7.09
0587	Natural Gas Jets 1.35	0.42
0588	Obsolete - Towns Gas Jet	-
0594	NG to LPG Conversion Kit	10.86
0598	Obsolete - Gas Valve Governor	-
0600	Obsolete - Screw	-
0602	Obsolete - Solenoid	-
0604	.77 jet	0.68
0615	Obsolete - Governor	-
0618	Obsolete - Wiring Harness	-
0620	Obsolete	-
0623	Obsolete - Clock Wire	-
0628	Microswitch	14.85
0637	Obsolete - 0.80 jets	-
0642	Obsolete	-
0652	Obsolete	-
0658	Microswitch	15.37
0659	Obsolete	-
0661	Obsolete - Flow Cup	-
066314	Obsolete - Badge	-
0666	Obsolete - By Pass Shutter	-
0667	O Ring	2.61
0680	Obsolete - Solenoid	-
0681	Obsolete - Spark Coil	-
0704	O Ring	1.14
0706	O Ring	1.24
0709	Spring	0.74
0714	Diaphragm	4.16
0716	O Ring	0.42
0717	Plate	4.17
0736	Obsolete - Clock Wires	-
0737	Obsolete - Wire Use 0738	-
0749	Obsolete	-
0750	Use 7625	-
077000	Obsolete - (R102399)	-
077085	Use 1859	-
077086	Use 1860	-
077939	Use 10027352	-
078125	Control Panel	27.68
078127	Linea Max wiring harness	148.32
078128	Obsolete - Cover (R102934)	-
078129	Control Panel Flap	16.38
078130	Linea Max wiring (inc h/l stat) Use 078127	219.77
078139	Pressure Gauge	10.94
078140	Use 106326	-
078617	Thermostat - Linea Max/Meteor	12.35
0795	Washer	0.68
0803	Obsolete	-
0809	Use 01005178	-

SPARE PARTS

Part No.	Description	Price
0811	Use 01005178	-
0828	Single Microswitch	11.37
0851	Nut	3.60
0852	By-Pass Bobbin	2.70
0855	Front Seal	5.82
0856	Front Seal Bush	6.49
0857	Spring	3.96
0858	Spindle Set	15.17
0862	Tail Plate	24.92
0863	3 Port Valve	15.11
0866	Obsolete - Screw For Domestic Manifold	-
08665	Use 10029306	-
0867	Front Seal	4.00
0869	Bearer Plate	5.70
0870	Diaphragm	4.63
0873	Non Return Nylon Body	29.89
0874	Obsolete - 1 Inch Nut	-
0875	Obsolete - Nylon Shuttle	-
0876	Obsolete - Dist Manifold	-
0877	Obsolete - Filter	-
0878	Obsolete - Non Return Brass Bod	-
088031	Use 10021792	-
088042	Obsolete	-
088106	Pipe	44.11
088107	Pipe	28.04
088108	Pipe	32.67
088110	Pipe	25.12
088111	Pipe	22.77
088112	Pipe	36.80
088113	Gas Pipe	21.07
088114	Gas Pipe	21.35
088115	Pipe	30.40
088116	Pipe	23.06
088117	Pipe	16.09
088118	Pipe	21.29
088119	Brass Connection	9.14
088120	Use 1488	-
088122	Manifold	296.64
088124	Use 1786	-
088125	Valve	10.95
088126	Use 1788	-
088127	Use 1789	-
088128	Use 1790	-
088129	Use 1791	-
088131	Use 1793	-
088132	Filling Loop Pipe (Straight Tube)	17.76
088133	Use 1821	-
088134	Use 1822	-
088135	Valve	13.15
088136	Nut	0.79
088137	Use 1824	1.28
088140	Filling Loop (2 right angles)	28.76
088153	Obsolete - Nut Small	-
088155	Heat Exchanger	145.76
088181	Expansion Vessel 10 Litre	89.00
088383	Flow Restrictor 18 litre	8.38
08948	Thermal Store Complete	412.42
0903	Obsolete - Fan Support Kit	-
0934	Use 0594	-
0935	Obsolete - Conversion Kit to NG	-
0940	Obsolete - Ignition Box	-
0950	Ignition Box	148.32
0963	Use 01005272	-
0975	Pressure Switch	48.10
0978	Obsolete - Pressure Switch	-
099862	Use 10025074	-
099864	Use 1837	-
OCR106339	Pipe	-
10020041	11L Flow governor (Beige)	4.02
10020054	Obsolete - Wiring Harness	-

SPARE PARTS

Part No.	Description	Price
10020076	Expansion Vessel Pipe	11.05
10020104	Burner (replaces 5295)	80.94
10020216	Cover Assembly	51.36
10020217	Cover Assembly	47.16
10020223	Use 0225	-
10020265	NG Injector	4.21
10020305	Obsolete - Cable	-
10020308	Obsolete - Logo Support	-
10020330	Use 10022349	-
10020335	Manifold Top Rep 2904	8.31
10020430	Air box cover rep 2061	57.26
10020437	Use 10021792	-
10020438	Pump	160.18
10020439	Heating manifold	65.26
10020477	Use 10024558	-
10020478	Use 10024528	-
10020493	Main Printed Circuit Board	160.18
10020511	Burner Nat Gas	124.76
10020512	Obsolete - Burner LPG	-
10020513	Main Heat Exchanger	172.05
10020514	Combustion Chamber Assembly	20.37
10020517	Front Insulation Panel for Combustion Chamber	7.55
10020518	Rear Insulation Panel for Combustion Chamber	7.84
10020519	Flow Pipe	11.47
10020520	Obsolete - Flow Pipe	-
10020521	Obsolete - Pump Pipe	-
10020522	Use 10024731	-
10020523	White Bracket	8.88
10020524	Lower Connection Plate	7.57
10020525	Obsolete - Fixing jig support	-
10020529	M3 to Heat thermistor, High limit stat, Burner stat & Analogue PD switch Wiring	41.57
10020530	M5 to DHW thermistor, Water pressure switch & DHW flow switch Wiring	20.72
10020597	Use 01005085 (Complete Frame)	-
10020599	Use 01005085 (Complete Frame)	-
10020601	Obsolete - Appliance Casing	-
10020603	Obsolete - Distribution Panel	-
10020604	Obsolete Upper Transverse Panel	-
10020605	Obsolete Lower Transverse Panel	-
10020607	PCB Cover	17.28
10020608	Cover Panel	3.14
10020609	Obsolete - Tap	-
10020610	LED Lens Tube	4.34
10020611	Pin	3.57
10020612	Pipe	18.80
10020613	Room sealed Chamber	81.50
10020615	M1 to High limit stat & Gas valve	39.75
10020616	M6 to Fan & PD switch	29.12
10020617	M4 to DHW thermistor, Heat thermistor, DHW Flow switch, Pressure switch & Modulator	54.73
10020621	Use 10022658	-
10020622	Pressure Gauge	18.12
10020624	Test Plate	1.38
10020625	Square Plastic Nut underneath Test Plate	2.24
10020626	Stop Clip (individual)	0.58
10020627	Fumes Testing Connection Pipe	3.73
10020631	Obsolete	-
10020645	Obsolete - Mode Selector Knob	-
10020647	Use 10020893	-
10020648	Obsolete - Pipe	-
10020649	Obsolete - Wiring Harness	-
10020661	Obsolete - Air Box Bottom	-
10020664	Pipe	24.50
10020666	Obsolete - Pipe	-
10020667	Gas Pipe	11.76
10020668	Obsolete - Connection	-
10020669	On/Off Shaft	3.75
10020670	Temperature Shaft	3.75

SPARE PARTS

Part No.	Description	Price
10020674	Knob	4.21
10020676	LED Light Guide	4.71
10020679	Case - Aquanova	51.77
10020687	Use 10028996	-
10020688	Full Loom	95.35
10020707	Distribution Manifold	286.97
10020714	Pipe	14.14
10020754	Obsolete - Clock Blanking	-
10020781	Obsolete - Pipe	-
10020793	Fan Assembly (includes Venturi)	79.84
10020799	Obsolete - Heating Manifold	-
10020838	Use 20040675	-
10020839	Expansion Vessel	104.79
10020840	Expansion Vessel	83.07
10020857	Use 0225	-
10020871	Non-Return/Double-Check Valve	19.14
10020885	Obsolete - Gas Pipe	-
10020886	Obsolete - Pipe	-
10020887	Obsolete - Pipe	-
10020889	Air Pressure Switch	36.26
10020890	Pressure Switch	33.89
10020891	Obsolete - Control panel	-
10020893	Obsolete - Mode selector shaft	-
10020894	Obsolete - Air Chamber	-
10020896	Option hanging bracket	5.83
10020897	Gas Cock	21.62
10020898	Safety Valve Outlet Tail	9.17
10020951	Obsolete - Front Panel	-
10020963	Use 10023603	-
10020966	Front Flap	15.81
10020967	Lower control panel right hand	6.90
10020968	Lower control panel left hand	6.90
10020973	Casing	56.54
10021005	Connection	19.14
10021006	Filling valve	8.85
10021021	Use 10025074	-
10021041	Flow Pipe	16.63
10021065	M3 to Heat thermistor, High limit stat, Burner stat & Analogue PD switch Wiring	42.62
10021080	Obsolete - Screws on Eclipse	-
10021108	M3 to Heat thermistor, High limit stat, Burner stat & Analogue PD switch Wiring	49.65
10021115	Obsolete - Clip	-
10021117	M9 to M2 ribbon cable from the main PCB to display the PCB	7.28
10021120	Instrument Panel Back Pan	23.52
10021127	Instrument Panel	35.79
10021131	Upper Proof	12.20
10021231	Main Heat Exchanger	136.46
10021232	Main Heat Exchanger	160.18
10021233	Wiring Tray	9.82
10021235	Thermostat	7.05
10021236	M3 to Heat thermistor, High limit stat & PD switch	30.04
10021240	Flow Pipe	21.62
10021241	Obsolete - Pipe	-
10021251	Manifold Extension	4.17
10021252	Air box bottom	60.89
10021253	Gas Valve	122.80
10021254	Gas Valve Outlet Pipe	10.83
10021255	Spark Electrode Inc Lead	13.29
10021256	Obsolete - Return Pipe	-
10021257	Flow Pipe	14.97
10021258	Return Pipe	14.14
10021259	Flow Pipe	16.63
10021260	Mynute 10e Instrument Panel	36.91
10021262	Use 10029470	-
10021263	Selection Switch Shaft	1.88
10021264	T/Stat & Mode Knob	1.98
10021265	PCB Cover	14.14

SPARE PARTS

Part No.	Description	Price
10021266	Obsolete - Terminal Block Cover	-
10021267	Obsolete - LED Lens	-
10021268	J3 to Gas valve & water pressure switch and J4 to the Pump Wiring	40.62
10021269	Wiring J6 to Fan PD switch & High limit stat and J7 to Heat thermistor (top half)	52.64
10021270	Wiring J6 to Fan PD switch & High limit stat and J7 to Heat thermistor (bottom half)	30.04
10021271	Wiring Socket Mynute 10/14/20E	30.04
10021272	Ignition Transformer with Wires	12.99
10021273	Use 1783 and cut down	-
10021287	Mynute 14E Instrument Panel	36.91
10021288	Air Box bottom	60.89
10021289	Obsolete - Return Pipe	12.99
10021290	Flow Pipe	14.48
10021291	Mynute 20E Instrument Panel	36.91
10021293	Distribution Manifold	284.74
10021294	Distribution Manifold	291.90
10021367	Heat Exchanger	218.41
10021398	Use 10025985	-
10021407	Wiring Harness	21.17
10021419	Main heat exchanger	211.46
10021420	Flue Gas Flange	1.69
10021519	Obsolete - Frame	-
10021558	Glass	11.54
10021568	Use 10024779	-
10021570	Obsolete - Cover Assembly	-
10021625	Non return valve	1.53
10021702	33mm Flue Restrictor Ring	1.70
10021726	Venturi for Fan	11.64
10021730	44mm Flue Restrictor Ring	1.70
10021792	Pump Rep 10020437	175.52
10021817	Spark Electrode Cable	24.50
10021821	Heating Distribution Manifold	74.11
10021847	Use 10024528	-
10021848	Use 10028891	-
10021849	PCB Cover Rep. 1855	16.72
10021899	Connection	23.52
10021901	Non return valve	15.31
10021906	Pipe	17.46
10021947	M14 to Ignition PCB & Gas Valve Wiring	40.04
10021949	Use 10027540	26.43
10021951	Instrument Panel	40.09
10021972	Fan Connection	19.17
10021973	Fumes testing connection pipe	3.64
10021984	Use 10029470	-
10021991	Use 10022659	-
10022000	Pipe - Replaces 2218	18.77
10022002	Flexible Pipe	17.28
10022015	Instrument Panel Replaces 1919	39.90
10022027	Use 10025891	-
10022029	Obsolete -Instrument panel 2075	-
10022112	M4 to Ignition PCB & Mod Coil	13.50
10022125	Pipe	15.70
10022174	Use 10028890	-
10022229	Use 20078519	-
10022278	Obsolete - Ht Exc Field fix	-
10022279	Obsolete - Ht Exc Field fix	-
10022282	Obsolete - Ht Exc Field fix	-
10022333	Eclipse 2 Wiring Harness	158.34
10022348	Use 10022349	-
10022349	DHW Actuator replaces 10020330	28.37
10022352	Use 10024731	-
10022355	Obsolete - Wiring Harness	180.48
10022388	Air box bottom	33.48
10022424	Shaft	1.18
10022441	Gas Valve	180.48
10022442	Gas Pipe	11.34
10022443	Obsolete - Inlet gas pipe	-
10022444	Obsolete - Eclipse Pump couplin	-
10022445	Obsolete - Eclipse flow pipe	-
10022450	Air Conveyor	154.28

SPARE PARTS

Part No.	Description	Price
10022451	Gas Diaphragm	2.04
10022453	Main Burner Injector LPG	5.76
10022483	M1 to motorised valve wiring harness	15.15
10022491	Use 10028996	-
10022499	Connection (replaces 2260)	3.77
10022518	Venting plug	11.78
10022530	Pipe	2.46
10022533	Main Printed Circuit Board	214.80
10022556	Pressure switch condensing	20.37
10022570	Cap	4.92
10022614	Fumes test connection pipe	4.04
10022620	Side Insulation Panel for Combustion Chamber	7.42
10022621	Use 10022620	-
10022622	Fan flue connection	5.30
10022626	Pipe	16.29
10022658	Connection	15.16
10022659	Ignition Transformer rep 10021991	18.94
10022666	Actuator cable	15.88
10022667	Combustion cable	28.20
10022668	Gas valve cable	17.55
10022671	Obsolete - Bracket	-
10022672	Room Sealed Chamber	59.29
10022685	Eclipse 226 ESC PCB NG & LPG	384.24
10022686	Eclipse 226 ESS PCB NG & LPG	384.24
10022687	Eclipse 216 ESS PCB NG & LPG	384.24
10022688	Use 10022685	-
10022689	Use 10022686	-
10022690	Use 10022687	-
10022714	Flue draught diverter	36.04
10022715	Combustion chamber	21.83
10022718	Fan	91.11
10022726	Washer	2.57
10022727	NG burner	164.68
10022826	LED light guide	3.45
10022853	Fan (replaces 8891 & 1018)	207.65
10022859	Obsolete - Pipe	-
10022860	Obsolete - Door panel	-
10022867	Obsolete - Siphon Connection	-
10022868	Obsolete - Siphon Pipe	-
10022980	NG burner	133.94
10022981	Hydraulic control cable	21.75
10023011	Cover	14.91
10023044	Bush (replaces 1863)	1.86
10023048	Fan to Flue Connector	10.38
10023051	Obsolete - Instrument panel	-
10023065	Use 10020898	-
10023066	Terminal Block and wires	26.43
10023067	M5 to Water pressure switch wiring	14.63
10023073	Valve	13.73
10023095	Air Box Bottom	50.44
10023136	Power wiring harness	7.49
10023168	NG burner	93.40
10023169	Burner	79.52
10023181	Fan/Flue Connector (includes Venturis)	13.09
10023182	Flue elbow	12.65
10023183	Fan/Flue Connector (Includes Venturi's)	41.18
10023185	Venturi	1.38
10023195	Use 1848	-
10023198	Pipe	21.36
10023202	Pipe	14.56
10023203	Pipe	23.72
10023208	Pipe	25.34
10023209	Pipe	13.71
10023210	Pipe	15.94
10023211	Pipe	14.27
10023235	Vent Plug	3.65
10023238	Cover Assembly	28.30
10023276	Obsolete - Flue Gas Flange	-
10023277	Obsolete - Instrument panel	-
10023279	Use 10027792 (log book included)	-

SPARE PARTS

Part No.	Description	Price
10023280	Flue Gas Flange	-
10023281	Instrument Panel	50.86
10023297	Display PCB	124.14
10023299	Input Printed Circuit Board	85.24
10023347	Instrument Panel	40.18
10023431	Thermo-pressure gauge	28.81
10023432	Use 10026050	-
10023451	Gas Injector (Worgas)	3.84
10023476	Obsolete - PCB Holding	-
10023477	Obsolete - Cover	-
10023478	Use 2033	-
10023479	Main Printed Circuit Board	384.24
10023482	Domestic Heat Exchanger	82.86
10023483	Obsolete - Heat Exchanger Jacket	-
10023486	Room Sealed Chamber	82.86
10023493	Obsolete - Connection	-
10023495	Siphon	54.20
10023530	Use 10026272	-
10023531	Siphon Plug	6.59
10023532	Locking Pin	12.35
10023533	O Ring	1.16
10023537	Printed Circuit Board - Green	202.64
10023549	Main Printed Circuit Board	440.54
10023566	Heating Flow Cock/Service Valve	28.22
10023567	C-Water inlet valve/Stop Cock - Screws into non return valve	27.83
10023568	Supply inlet valve	19.61
10023569	Non-Return/Double-Check Valve	19.32
10023570	Flexible Pipe/Filling Loop	20.93
10023571	Obsolete - Bracket	-
10023573	Obsolete - Pump Cable	-
10023574	Obsolete - Pipe	-
10023575	Obsolete - Pipe	-
10023576	Pipe	33.27
10023577	Pipe	32.94
10023578	Obsolete - Pipe	-
10023579	Pipe	28.57
10023580	Connection Pipe	16.07
10023582	Membrane Keypad	49.40
10023583	Obsolete - LED Light Guide	-
10023584	Obsolete - Diverter valve cable	-
10023585	Use 10024392	-
10023586	Flat Cable (Hydra)	67.38
10023587	Wiring M6 to DHW Thermistor (NTC3)	9.14
10023589	Obsolete - Outer casing - Hydra	-
10023603	Flexible Expansion Pipe	17.63
10023643	S.Valve outlet tail repl.1792	15.66
10023651	Use 20005146	-
10023661	Main heat exchanger Rep 20005151	231.38
10023681	Cover	5.06
10023697	Obsolete - Pipe	-
10023699	Washer	0.47
10023763	Display board	64.84
10023764	Use 10024393	-
10023772	Obsolete - Door Panel	-
10023774	Obsolete - Door Panel	-
10023798	Burner	63.41
10023799	Burner	45.61
10023805	Metal Air Box Hole Cap	3.30
10023810	Door Panel	11.16
10023812	Obsolete - Cover	-
10023816	LED Light Guide	2.65
10023817	Use 10030336	-
10023818	Use 10030335	-
10023822	Case	82.34
10023823	Compact 28 Case	90.58
10023834	Burner	124.18
10023836	Use 20020377	-

SPARE PARTS

Part No.	Description	Price
10023838	CN8 to Primary NTC,Air Press switch,High limit stat & CN4 to Fan	47.86
10023840	CN1 to M3 external connections block	41.18
10023878	Main Heat exchanger	266.73
10023891	Membrane keypad	59.33
10023892	LED Light guide	2.35
10023901	Burner	73.28
10023902	Main Burnerinjector manifold	55.09
10023904	Air box bottom	75.20
10023907	Fan Assembly Includes Venturi	123.50
10023908	Air Pressure Switch	41.99
10023909	Rear Insulation Panel for Combustion Chamber	5.27
10023910	Front Insulation Panel for Combustion Chamber	6.91
10023928	Cover Assembly	35.41
10023931	Room Sealed Chamber	77.40
10023933	Use 20001126 - Will need to change all fascia components to fit new version	-
10023935	Clock bezel for 10028496 & 10023938	3.96
10023936	Use 10030336	-
10023937	Control Knob - Will need to change all fascia components to fit new version	2.32
10023938	Use 10028496	-
10023939	CN5 to Gas valve, CN2 to Pump & CN9 to Water pressure switch,Modulator,DHW thermistor & DHW Flow switch	47.76
10023940	M6 (Connections block) to Clock	9.52
10023942	Use 10027793 (log.book included)	-
10023945	Room Sealed Chamber	129.28
10023946	Heat exchanger	361.66
10023947	Long Pipe from Heat Exchanger	20.59
10023948	Flexible Pipe (Black Rubber Section at End)	18.94
10023949	Pipe	30.83
10023950	Pipe	14.82
10023996	Gas Pipe	13.84
10023997	Obsolete - Burner Flange	-
10024019	Press Gauge (Old Type) Sits Behind Control Panel	13.42
10024026	Clamp	4.65
10024035	Fan	150.28
10024037	Use 20020309	-
10024042	46mm Restrictor Ring	2.37
10024043	47mm Restrictor Ring	2.37
10024044	49mm Restrictor Ring	2.37
10024067	CN8 to Heat thermistor, Pressure Differential switch, DHW Flow switch & CN4 to the Fan	50.23
10024112	Siphon	38.57
10024120	M3 to Heat thermistor, High limit stat, Burner stat & PD switch (Also comes M1 to condense sensor & M12 to fan)	48.06
10024121	Use 20006403	-
10024125	Hood Assembly	33.78
10024126	Clamp	15.70
10024129	Short Pipe from Condense Unit	22.17
10024130	Pipe	16.18
10024131	Pipe	14.82
10024132	Use 20068881	-
10024133	Siphon plug	4.08
10024136	Retarder	56.70
10024137	Fan flue connection	32.43
10024140	Use 10025212	-
10024141	O Ring	14.02
10024142	O Ring	0.58
10024143	O Ring	9.69
10024157	CN8 To Primary NTC, PD Switch & High Limit. CN4 to Fan	25.70
10024166	Air box side	21.16
10024173	Use 10024976	17.23
10024191	Pressure tube	1.29
10024230	Fan	260.13
10024295	Use 20015932	33.94
10024301	Heat exchanger	197.57
10024310	Flue Hood Assembly	18.25

SPARE PARTS

Part No.	Description	Price
10024311	Short Pipe from Condense Unit	21.32
10024312	Pipe	16.99
10024313	Pipe	14.02
10024314	M3 to Heat Thermistor, High Limit, Burner Stat & Analogue Pressure Switch. Also includes M1 to Condense Sensor & M12 to Fan	48.06
10024323	Obsolete - Blanking Plate	6.17
10024326	Use 10024731	191.82
10024336	Clip	21.32
10024342	M5 to DHW thermistor, Water pressure switch & DHW flow switch	17.55
10024364	Plate (replaces S10013)	7.51
10024384	Use 1817	6.00
10024390	Main Printed Circuit Board	251.37
10024392	X1,X2,X3,X4 Near Full Loom	181.16
10024393	X1,X2 & X3 Near Full Loom	136.91
10024440	Use 20068882 Plastic Pipe	-
10024449	Use 20081537	-
10024462	9L Flow governor (Orange)	5.74
10024463	NG Burner	110.25
10024464	Obsolete - LPG burner	-
10024466	M4 to Ignition PCB & Gas valve Wiring	14.21
10024467	Use 10027794	-
10024468	Linea 726/730/735 user manual	-
10024473	Hood Assembly	29.72
10024498	Instrument Panel	18.43
10024508	Door panel rep 10024530	14.02
10024518	Pipe	22.98
10024519	Pipe	15.93
10024520	Pipe	16.47
10024521	Use 20068884	-
10024522	M12 To Fan, M1 to Condense Sensor, M3 to PD Switch, High Limit, Burner Stat, Primary NTC	48.06
10024524	NG burner	106.65
10024526	Fan	124.59
10024528	Main Printed Circuit Board (Rep 10021847) & 10020907	133.33
10024530	Use 10024508	-
10024554	Use 20028963	-
10024558	Control Printed circuit board - rep 10020477	70.17
10024573	Obsolete	-
10024577	Fan	160.18
10024578	Main heat exchanger	190.71
10024579	Main heat exchanger	231.38
10024580	Main heat exchanger	226.84
10024627	Domestic heat exchanger	89.00
10024640	Use 10030114	-
10024641	By-pass casing	12.78
10024642	By-pass body	10.01
10024643	Cover for by-pass Assembly	9.35
10024645	Automatic by-pass plug	3.95
10024646	Discharge Valve with O Ring (10025064) & Washer (10025066)	6.59
10024647	Connection	3.26
10024662	Expansion vessel	125.25
10024668	Pipe	25.43
10024669	Room Sealed chamber	59.33
10024670	Combustion Chamber Front Cover	14.95
10024672	Pipe	24.09
10024673	Pipe	38.85
10024676	Front cover	22.07
10024680	LED light guide	15.25
10024681	Gear wheel	1.74
10024682	Gear wheel	1.82
10024686	Hole cover	1.44
10024687	Hole cover	2.32
10024688	Obsolete - Hole cover	-
10024689	CN1 To Fused Terminal Block & Control Terminal Block	42.91
10024692	Casing Kit for Rain boiler	125.25
10024710	Limit thermostat	10.07
10024718	Spreader bar	6.98
10024731	Printed circuit board	236.97
10024740	Hydraulic control cable	15.38

SPARE PARTS

Part No.	Description	Price
10024742	Burner injector manifold	46.84
10024745	Air Box Bottom	45.28
10024751	Combustion chamber	38.43
10024752	Burner (NG)	85.43
10024756	Instrument panel	34.69
10024757	Front flap	15.63
10024759	Use 10027801	-
10024779	Cover for Air Box rep 10021568	20.37
10024794	Combustion Chamber Front (Metal)	8.06
10024799	Pipe	16.11
10024800	Pipe	16.11
10024801	Pipe	14.98
10024802	Pipe	22.69
10024957	Use 10027571	-
10024958	Locking Pin	0.84
10024976	Rear cover	10.76
10024982	Pipe	7.39
10024983	Pipe	8.96
10024985	Nipple	9.86
10024986	Locking Pin	0.84
10024987	Flow governor 10 Litres Per Minute (Blue)	5.34
10024988	O Ring	0.68
10025055	Use 20044364	-
10025056	Non return valve	4.37
10025057	Pipe	9.03
10025059	Connection	9.86
10025060	Filling Cock	35.05
10025061	Use 10027351	-
10025062	Locking Pin	0.84
10025063	Locking Pin	0.84
10025064	O Ring	4.53
10025065	O Ring	1.59
10025066	Washer	2.80
10025067	O Ring	2.22
10025068	Silicone Tube	2.22
10025074	Use 20035533 (R106332) (R102866)	-
10025080	Flow governor 12 Litres per Minute (Red)	5.55
10025188	Flexible pipe for Expansion vessel	13.19
10025212	Condensing level detector	35.22
10025270	NG Burner	50.11
10025271	Main Burner injector manifold	39.19
10025304	Actuator/Motorised valve	53.97
10025305	3 way valve cartridge	57.03
10025312	Electric connections Kit	104.20
10025340	Printed circuit board - Green	198.60
10025348	Pressure gauge	7.42
10025368	Wiring harness	66.02
10025370	CN4 to fan & CN8 to NTC, Limit stat & flue press switch	40.09
10025449	Curved Locking Pin	2.04
10025450	Fixing fork wrench	13.57
10025461	Injector 4.8	9.25
10025468	Fan Baffle Compact 25HE	9.04
10025485	Auto air vent bottle (Pump)	15.88
10025647	Fan Baffle	9.04
10025726	Use 20001140	-
10025728	Sabre 24 casing	108.14
10025731	Fixing flange	111.23
10025733	Water supply stop cock	19.88
10025739	Sabre 28 casing	108.14
10025833	Obsolete	-
10025839	Pipe	16.05
10025840	Pipe	10.72
10025842	Front Panel	17.64
10025891	Spark / ignition electrode with lead	16.11
10025911	Main Printed Circuit Board	246.38
10025934	Hood Assembly	23.76
10025935	Combustion chamber	13.27
10025938	Fan	149.51
10025941	Combustion - Fan cable	55.28

SPARE PARTS

Part No.	Description	Price
10025961	Obsolete - Pipe	-
10025962	Obsolete - Pipe	-
10025963	Obsolete - Pump cable	-
10025985	Spark / ignition electrode with lead Rep 10021398	14.42
10026008	Fan Baffle Compact 29HE	9.04
10026031	Ignition transformer TR6 with wires	10.10
10026041	Flow governor 13 Litres per Minute (Olive Green)	5.08
10026042	Flow governor 15 Litres per Minute (Lime Green)	5.08
10026043	Flow governor 8 Litres Per Min (White)	5.34
10026044	Flow governor 9 Litres Per Minute (Orange)	4.14
10026045	Flow governor 11 Litres per Minute (Beige)	4.14
10026046	Flow governor 14 Litres per Minute (Pink)	5.08
10026050	Thermo-Pressure gauge	32.17
10026071	Obsolete - Instrument panel	-
10026097	Plug	-
10026098	CN5 to Gas Valve, CN9 to water pressure switch & modulator & CN2 to Pump Wiring	27.37
10026102	Burner	37.88
10026116	Cover	32.91
10026164	Case	81.06
10026179	Casing - Compact 29HE / Procombi 100HE	81.06
10026193	Pipe	13.84
10026194	Use 20092620	-
10026203	Casing - Sabre 25 HE	69.90
10026228	Pipe	16.60
10026230	Room sealed chamber cover	36.67
10026231	Room sealed chamber side	27.48
10026232	Test Point Cap	2.26
10026236	Transformer with wires that connect onto CN01	77.08
10026237	Use 20002969	-
10026238	Use 10029365	-
10026239	Cover Assembly	27.20
10026240	Use 20007052	-
10026241	Casing	109.42
10026247	Pressure gauge	19.98
10026264	Pipe	16.05
10026265	Obsolete - Pipe	-
10026266	Obsolete - Pipe	-
10026267	Pipe (Rep 10027317)	24.09
10026268	Obsolete	-
10026269	Clip	0.84
10026272	Flexible Pipe	7.10
10026273	Use 20081926	-
10026275	Use 10029306	-
10026309	Use 10028420	-
10026310	Use 20007053	-
10026311	Use 10028421	-
10026316	Sensing electrode	10.52
10026317	Use 10028204	-
10026318	Gas pipe	13.67
10026322	Washer	18.52
10026323	Washer	11.10
10026324	O Ring	2.42
10026325	O Ring	2.15
10026328	Glass Assembly	7.10
10026329	Silver Metal Bracket for Conveyor on Linea HE	2.10
10026330	Wiring J15 & CN3 to M10 connector (external sensor/ U.H.T)	34.17
10026331	J9 to Motorised Valve (With the second pump connection for underfloor htg etc)	15.08
10026332	CN02 to Fan & CN1 to Condense sensor,Flow thermistor & return thermistor (now with J12 & condense sensor)	40.76
10026333	J3 Mains terminal block & wires	26.73
10026335	Obsolete - Low tension cable	-
10026336	J10 to Gas valve cable	20.49
10026337	CN01 to Fan transformer	21.39
10026338	J8 to Pump Wiring Harness	13.86
10026339	Use 10028363	-
10026341	Ribbon Cable	14.76
10026342	Cable Connector	6.64
10026345	Washer	5.86
10026346	Silicone pipe	0.53
10026355	Combustion chamber cover	6.38

SPARE PARTS

Part No.	Description	Price
10026359	Venturi	11.16
10026366	Washer	4.63
10026372	Hood Assembly	13.57
10026384	Cover	28.65
10026404	Printed Circuit Board (Small)	-
10026405	Obsolete - Hood Assembly	-
10026406	Obsolete	-
10026407	Fan	151.02
10026408	Combustion - Fan cable	55.28
10026409	Use 10027795 (log book included)	-
10026412	Obsolete - Pipe	-
10026413	Obsolete - Pipe	-
10026422	Pipe	14.10
10026423	Pipe	14.10
10026424	Pipe	13.02
10026429	Open therm Ribbon Cable	38.42
10026475	Use 10027599	-
10026491	Use 10028202 (expl diag incl)	-
10026494	O Ring	0.63
10026506	Heating manifold	70.55
10026507	Valve	62.61
10026508	Heating manifold & cartridge (3 P.V Kit)	65.97
10026545	Pipe	4.44
10026547	Linea HE heat exchanger (Special)	122.41
10026548	Use 10028537	-
10026552	Pipe	14.70
10026558	TSC1 (ignition transformer) to Spark electrode Wiring	9.23
10026671	Fixing Flange	3.37
10026686	Connection band CN4 to J1 on display PCB	6.93
10026698	Use 10028203	-
10026701	Obsolete - Pipe	-
10026703	Gas Pipe	26.28
10026721	Thermostat	13.27
10026771	Use 10026098	-
10026791	Clamp	1.74
10026796	Fan Gasket	6.14
10026857	Fitting/Union	30.28
10026866	Casing	135.58
10026933	Block with combustion analysis check	7.88
10026982	Limit stat	8.27
10026983	Use 10027360	-
10027015	Use 20000773	-
10027040	Flexible pipe	4.90
10027051	Fan	246.68
10027089	Tryton	9.23
10027132	Use 10028142	-
10027135	Pressure gauge	18.52
10027146	Pipe	24.93
10027158	CN2 to W Pressure sensor, DHW Flow switch, DHW temperature wiring	27.75
10027159	LPG Injector (3.6)	5.16
10027161	LPG to NG jet (6.7)	6.81
10027162	NG jet (7.0)	6.81
10027175	Air box bottom	106.40
10027187	Use 20039202	-
10027190	Use 10028405	-
10027191	Pipe	6.46
10027192	Flexible pipe	5.86
10027193	Washer	0.95
10027196	Use 10028206	-
10027200	Driver PCB	44.70
10027258	Pump	136.46
10027316	Fan	147.16
10027317	Use 10026267	-
10027318	Use 20020179	-
10027320	Pipe	21.29
10027321	Use 10029458	-
10027335	Pressure reducing valve	51.05
10027343	3 way heating man & cartridge	62.91

SPARE PARTS

Part No.	Description	Price
10027351	Thermistor/NTC Sensor	6.65
10027352	Thermistor/NTC Sensor (20004978)	11.45
10027360	J12 Link wire between heat exchanger thermostat & flow overheat stat	3.10
10027370	Use 20002906	-
10027408	Mixer	45.15
10027410	Insulation Kit	2.45
10027502	Compact HE 25/29 installation manual	-
10027533	Air Box Bottom	49.73
10027535	Condense Pressure switch	22.24
10027536	NG burner	92.73
10027537	Gas pipe	14.08
10027538	Pitot pipe from venturi Kit 01005405	2.37
10027540	Condense Unit Washer	7.59
10027541	Pipe	36.31
10027542	Pipe	23.09
10027543	Use 20066456	-
10027544	Pipe	10.90
10027545	Flexible pipe	7.59
10027546	Siphon	54.87
10027547	Use 20001102	-
10027549	Use 20001101	-
10027553	88mm Restrictor ring (100-88)	0.84
10027554	40mm Restrictor ring (80-40)	0.84
10027555	45mm Restrictor ring (80-45)	0.84
10027558	Wiring harness CN4 to Fan & CN8 to Heat Thermistor, PD switch & high limit stat wiring	68.39
10027559	Air box bottom	44.18
10027562	Air box bottom	47.42
10027564	NG Burner	106.69
10027566	Pipe	32.10
10027567	Pipe	21.98
10027568	Use 20066460	23.09
10027569	82.5mm Restrictor ring (100-84)	0.84
10027571	Pump	160.18
10027578	Cover	23.99
10027580	Sabre HE combi user guide	-
10027581	Use 10028019	-
10027599	Cover Assembly	17.18
10027620	Spark/Ignition electrode Replaced	17.80
10027685	Connections cover	33.01
10027709	Pipe	29.63
10027712	Use 20001141	-
10027713	Wiring harness	35.31
10027739	Gas pipe	28.14
10027742	Pipe	36.13
10027757	Locking Pin	0.63
10027758	Hydraulic control cable	37.47
10027768	Heating manifold & Cartridge	53.62
10027806	3/4" gas cock	25.21
10027807	Obsolete - Heating cock	-
10027841	Pipe	9.63
10027845	Flange Ø 42	0.79
10027864	Spark/ignition electrode	25.41
10027896	Pipe	11.59
10027898	M12 to Fan & M3 to Heat thermistor, high limit stat and Air pressure switch	43.80
10027913	CN4 to Fan & CN8 to Heat Thermistor, PD switch & high limit stat wiring	20.12
10027949	Front Panel	146.81
10027952	J9 to M2 Second Pump	10.72
10027953	Wiring harness	13.84
10027975	Pipe	37.54
10027990	Pipe	29.46
10028002	White Caps	1.13
10028011	Air Box Bottom	52.76
10028013	NG Burner	86.44
10028014	Gas pipe	21.48
10028015	Use 20066463	-
10028016	Casing Sabre 35 HE	127.35
10028025	Case - Compact 35HE	115.71
10028045	Compact HE installation manual (25,29,35)	-
10028428	Pipe	14.27

SPARE PARTS

Part No.	Description	Price
10028141	Water Pressure switch	14.98
10028142	Pressure Transducer Rep 10027132	16.96
10028155	Pipe	26.40
10028203	Gas pipe	12.32
10028204	Pipe	94.55
10028206	Gas Pipe Replaced 10027196	19.79
10028263	Use 20019769	-
10028264	Use 20020179	-
10028341	Room sealed chamber	41.53
10028345	Cover for air box	40.95
10028363	Wiring harness/condense sensor Rep 10026339	16.34
10028393	Obsolete - Casing	128.91
10028405	Siphon	46.03
10028415	Heating manifold	64.94
10028420	Air gas conveyor	42.35
10028421	Flue drain connection Replaced 10026311	8.19
10028422	Flame detection electrode	18.08
10028423	Gas pipe	12.39
10028424	Use 10030381	-
10028425	Tryton	11.59
10028426	Washer	7.33
10028427	Use 10028904	12.39
10028428	Pipe	14.98
10028429	Use 20020182	-
10028430	Air bleeding connection Pipe	9.63
10028431	Cock	7.92
10028432	Casing	132.37
10028447	Air box bottom	54.30
10028448	Casing	132.37
10028451	Use 20019250	-
10028454	PCB	104.50
10028456	Fan	264.59
10028467	Electrode	9.62
10028474	Use 20001103	-
10028475	Knob	3.39
10028476	Knob	3.39
10028477	Timer carrier	5.04
10028479	Room sealed chamber	59.33
10028482	Spark Electrode Cable	13.44
10028492	Pipe	20.88
10028493	Pipe	12.14
10028494	Pipe	23.99
10028495	Pipe	17.77
10028496	Mechanical Timer (Rep 10023938)	68.32
10028503	Blanking plate	1.11
10028506	Pipe	24.53
10028515	Use 20019766	-
10028516	Use 20019766	-
10028517	Pipe	7.28
10028531	CN3 to Motorised Valve, CN2 to Pump, CN5 to Gas Valve & Solenoids & CN9 to Pres Switch, Condense Pres Switch, Modulator, DHW Thermistor & DHW FloSwitch	68.59
10028533	Tube	7.23
10028535	Expansion vessel	70.55
10028536	Use 20008306	-
10028537	Burner (Rep 01005458 and 10026548)	135.48
10028538	Use 20039202	-
10028539	Condensing pipe	9.30
10028540	Condensing pipe	4.54
10028551	Instrument Panel	26.83
10028553	Use 10030136	-
10028554	Cover Assembly	21.77
10028557	LED light guide	3.39
10028558	Use 20008307	-
10028559	Knob Assembly	4.81
10028593	X2 to M4 to open therm plus connection & external sensor Wiring	18.65
10028594	CN5 to Pump Wiring harness	15.51
10028595	X4 to Fan Signal Control, FA2 to Condense Sensor & Sense Electrode	45.15
10028596	Wiring CN1 to M5 room thermostat & M3 terminal block	38.70
10028597	Earth connection	2.13

SPARE PARTS

Part No.	Description	Price
10028598	Wiring X16 to Water pressure switch	7.33
10028599	Wiring CN3 to Gas valve & solenoids	18.65
10028600	Wiring CN1 to Fan power supply, CN2 to ign transformer	34.43
10028601	X9 to M3a Terminal Strip, Return NTC & Flow	45.40
10028603	Pipe	10.98
10028617	Pipe	19.79
10028618	Use 10028906	-
10028620	Gas pipe	12.68
10028623	Use 20007053	-
10028625	Use 10028905	-
10028626	CN1 To Fan Power Supply, CN2 to Ign Transformer	34.17
10028628	Gas pipe	12.68
10028629	Gas pipe	13.02
10028631	Pipe	27.11
10028632	Instrument Panel	29.62
10028633	Wiring CN5 to Pump & 3 way motor	30.51
10028634	Wiring X16 to Water pressure switch, DHW flow switch & DHW temp thermistor	20.33
10028642	Burner	119.31
10028643	Pipe	25.41
10028747	Pipe	31.84
10028809	Frame Assembly	180.43
10028811	Expansion vessel	71.56
10028812	Distributor	79.75
10028813	Gas pipe	13.14
10028814	Gas pipe	10.83
10028815	Gas pipe	14.14
10028816	Pump 15-60	163.86
10028817	Pipe	34.93
10028818	Pipe	14.95
10028819	Pipe	9.16
10028820	Pipe	14.91
10028824	J15 to M10 Block to CN3	22.13
10028825	Wiring CN2 To DHW NTC, DHW Flowswitch, Water pressure sensor	24.82
10028826	Wiring CN1 TO NTC1, NTC2, Condence sensor, J12 to overheat stats, CN02 to fan	34.26
10028827	Wiring Mains terminal block to J3 & wires	29.37
10028828	Wiring CN2 To DHW NTC, DHW Flowswitch, Water pressure sensor	20.42
10028829	Wiring J10 To Gas Valve	18.59
10028831	Wiring	9.09
10028834	Frost protection resistors	90.56
10028839	Door panel	16.82
10028865	Combustion cable	46.69
10028868	Gas pipe	13.35
10028869	Gas pipe	9.82
10028880	REC07 interface PCB	31.00
10028890	Flame control ignition module (Rep 10022174)	105.70
10028891	Ignition module (Rep 10021848)	88.45
10028894	Quick primer pressure gauge	14.73
10028899	Burner NG	72.32
10028902	Case clips	3.98
10028903	Case clips	3.98
10028904	Pipe	19.87
10028905	Pipe	26.17
10028906	Pipe	25.70
10028996	Use 20028963	-
10029007	Pipe	15.15
10029032	Wiring M2 to External Pump	7.83
10029105	Water gauge carrier	6.90
10029107	Wiring Harness	17.85
10029108	Wiring Harness	10.55
10029209	Injector (5.7)	3.56
10029212	Use 20007052	-
10029279	Expansion vessel	92.87
10029296	Pipe	39.06
10029305	Gas pipe	12.63
10029306	Auto air vent (Brass) Replaced 100618	16.99
10029365	Display Panel - Replaced 10026238	152.08

SPARE PARTS

Part No.	Description	Price
10029415	Instrument Panel	31.31
10029417	Door Panel	12.20
10029420	Printed circuit board	75.36
10029421	Pressure gauge (New Type) - Hole Completely Cut Out	22.81
10029422	Actuator cable	12.20
10029423	Pump cable	14.33
10029424	M16 to Connection Block & Clock, Fuse Block & Fly Lead	32.63
10029425	Gas valve cable	24.94
10029426	Combustion cable	46.69
10029427	Control cable	21.22
10029429	Combustion cable	47.22
10029442	Pipe	37.68
10029443	Pipe	38.21
10029457	Use 20019769	-
10029458	Use 20020179	-
10029470	Main Printed circuit board	128.53
10029515	Use 20020182	-
10029526	Connection	9.03
10029574	Blanking plate	1.85
10029585	Badge	3.55
10029590	Pipe	12.84
10029591	Pipe	12.11
10029592	Pipe	9.06
10029607	Gas pipe	10.35
10029715	Use 20081926	-
10029717	Main Printed Circuit Board	160.79
10029757	Heating Cock 28mm	32.49
10029823	Glass flange Assembly	7.88
10029850	Pipe	61.79
10029961	Pipe	19.92
10029963	Gas pipe	9.95
10029965	Safety valve P & T	53.27
10029967	Fixing flange	9.75
10029968	Nipple	11.32
10029969	Boiler outlet tube	33.09
10029975	Pipe	27.70
10030114	Connection	9.24
10030117	NG burner	69.94
10030123	Pipe	18.80
10030124	Knob	2.94
10030125	Knob Assembly	2.94
10030126	Door panel	16.58
10030136	Door flap	3.78
10030214	Support	3.09
10030255	Door panel	9.65
10030311	Hanging bracket	8.75
10030335	Temperature control knob	2.08
10030336	Selector Knob - Will need to change all fascia components to fit new version	1.88
10030381	Gas pipe rep 10028424	37.97
10030433	Dual Printed circuit board - Red	202.64
10030440	Pipe	21.00
10030505	Dual Printed circuit board - Red	267.88
10030506	Test point plugs	3.21
1006	Bolt head Screw	1.45
100618	Use 10029306	-
1007040	Flexible pipe	4.33
100940	Use 48382	-
1011	Obsolete - Flow Pipe	-
1012	Obsolete - Flow Pipe	-
1013	Obsolete - Flow Pipe	-
1014	Use 1191	-
1016	Insulation Panel	2.85
1018	Use 10022853	-
1019	Burner Gasket	28.14
1022	Washer Ring	0.26
102402	Use 1859	-
102403	Use 1860	-
1028	Obsolete - Wiring Harness	-
1029	Obsolete - Wiring Harness	-

SPARE PARTS

Part No.	Description	Price
102921	Linea Max HE Flue Tee	23.74
102965	System return pipe	21.77
103277	Closing pin	0.84
1033	Cover for condensing Assembly	172.05
1035	Front Panel for Air Box	40.75
103539	Key	0.84
1037	Obsolete - P.C.B. Cover	-
1041	Obsolete - Velcro Fastener	-
104199	Use 078617	-
1042	Obsolete - Dist Manifold	-
104268	Non Return Valve	20.65
1044	Electrode	16.63
1045	Pump Cable	16.38
104654	Outside probe	27.46
1048	Obsolete - Transformer	-
1050	Use 10020438	-
105852	Solar Grey (Cylinder) Probe SPF 1000	113.01
105898	Main wiring	49.73
105899	Master wiring	65.57
105900	Slave wiring	136.64
105901	Ignition cable	81.97
105902	Bend	29.58
105903	Burner head silicone gasket	10.93
105904	Use 20102262	-
105906	Green on off switch (oblong)	10.93
105907	Round green on off switch	13.67
105908	Gasket/screw Kit for venturi	36.16
105910	Flue gas analysis test point with plug (Rep B81515)	65.57
105911	Bulkhead connector for the condensate	15.44
105912	Cock	21.02
105913	Use B81511	-
105914	Ignition/detection electrode	73.46
105915	FE flange for exchanger pipe	16.39
105916	Silicone gasket for ignition plug	10.93
105917	Viton gasket	42.95
105918	Use 20049127	-
105919	Condensate drain trap quick fit	56.50
105920	Pijnenburg master board	546.53
105921	Use 107934	-
105922	Use 7236	-
105924	Temperature probe	41.82
105926	Thermostat	10.93
105930	Air vent valve	13.67
105931	Fan	419.74
105932	Venturi	166.79
105965	Upper Front Panel	95.77
105966	Front Panel	361.62
105967	Front Panel	180.81
105968	Right Panel	125.44
105969	Left Panel	90.41
105970	Gas Pipe	76.28
105971	Gas Inlet Pipe Condexa Pro	68.82
105973	Instrument Panel	54.74
105974	Panel & Cover Slave	60.18
105975	Top Rear	110.19
106250	Gas valve	312.68
106252	Pressure diff switch	173.25
106254	Serial cables	32.04
106277	Detector	68.63
106323	Use 10022556	-
106324	Condense drain pipe	43.19
106325	Use 10027546	-
106326	Control Panel Complete	494.90
106327	Management board	316.60
106328	Complete wiring	197.62
106330	Use 10023568 (Small V) & 10023566 (large V)	-
106331	Use 10025188	-
106333	Use 2573	-
106334	Instrument panel cover	21.85
106335	Wiring	9.54

SPARE PARTS

Part No.	Description	Price
106336	Condensate drain pipe	15.51
106337	Pipe	143.48
106338	Safety valve	71.65
106339	Pipe	19.89
106368	Gas Pipe	28.26
106513	Collector & tank probe	38.31
106791	Master board (Incorrect Board use R107584)	456.38
106792	Master Box	58.47
106847	Instrument Panel	128.82
106849	Digital display frame Assembly	53.39
107180	Condexa Pro LPG Conversion Kit 2 washers 6.5 and 6.75	16.96
107393	Ignition/detection electrode	83.63
107428	Use 105919	-
107529	Use 10023566 (L) & 10023568 (S)	-
107584	Master board Replaced R106791	456.38
107934	Pijnenburgh slave board	499.41
1095	Wiring M3 to thermistor, High limit stat & Air pressure switch	42.34
11300	Screw	3.39
11304	Obsolete - Screw	-
11305	Use 1890	-
11322	Obsolete - Cover	-
1133	Obsolete - Back Frame	-
1140	Use 7315	-
1141	Fan Flue Connection	10.99
1191	Siphon	18.80
1192	Siphon pipe	8.33
1193	Front Insulation Panel	21.54
1194	NTC Sensor	11.39
1195	Main Burnersupport	16.53
1196	Main Burner	187.88
131ZEB3A	Obsolete - LPG Conversion Kit Meteor	-
1321	Flow governor (Green)	3.10
1322	Flow governor	2.39
1329	Expansion vessel	47.45
1439	Obsolete - Pressure Switch	-
1440	Bracket	15.48
1453	Baffle	47.69
1457	Silicone tube (1 Metre)	1.74
1466	Flow governor (Blank)	1.49
1488	Flow Switch / Actuator	29.00
1489	Water filter	2.37
1490	Use 1488	-
1493	Input P.C.B.	37.28
1494	Obsolete - Wiring Harness	-
1495	Obsolete - Wiring Harness	-
1498	Front Flap (New Linea)	17.19
1531	Use 10020216	-
1547	3 Core Fly Lead	6.89
1548	Cover for Air Box	34.92
1549	Air Chamber Side Panel Rep 1878/48928	21.62
1552	Valve For DHW Bypass	6.64
1592	3/4" Heat water cock	13.45
1604	Flow governor (White)	3.56
1606	Obsolete - Air Box Bottom	-
1607	Obsolete - Air Box Bottom	-
1631	Use 8460	-
1639	Obsolete - Control Panel	-
1642	Obsolete - Bracket	-
1650763	Obsolete Hydra/Pinnacle heat engine	-
1704	Obsolete - Air Vent	-
1730	Obsolete - Eclipse ESC PCB NG	-
1731	Obsolete - Eclipse ESC PCB NG	-
1732	Obsolete - Eclipse ESS PCB NG	-
1733	Obsolete - Eclipse ESS PCB	-
1734	Heating By-pass Valve	6.64
1749	Water Stop Cock	21.40

SPARE PARTS

Part No.	Description	Price
1777	Obsolete - Upright Frame (Left)	-
1778	Obsolete - Upright Frame (Right)	-
1779	Use 10022125	-
1780	Internal clock wire	15.89
1781	Obsolete	-
1783	Hanging bracket	4.63
1783A	Obsolete - Hanging Bracket	-
1784	Obsolete - Plate	-
1785	Obsolete	-
1786	C-Water inlet valve/Stop Cock - Stands alone	20.46
1787	Gas Cock	13.90
1788	Heating Flow Cock/Service Valve	22.01
1789	Heating Cock 22mm (Washers are 5237)	20.46
1790	Connection Rep 088128	13.16
1791	Double Non Return Valve	17.28
1792	Use 10023643	-
1793	Brass Nut Rep 088131	6.15
1794	Flexible Pipe/Filling Loop	24.45
1806	Safety Valve (Push Fit)	14.55
1807	Use 20007057	-
1816	Obsolete - Dist Manifold	407.52
1817	Hanging bracket - Replaced 10024384	7.17
1820	Clip	0.79
1821	Olive (Small)	0.42
1822	Olive (Large)	0.53
1823	Nut (Small)	1.27
1824	Nut (Large)	1.27
1828	Obsolete	-
1829	Expansion Vessel Plate	2.92
1830	8 Litre Expansion Vessel (Inc pipe)	89.00
1831	Use 2127	-
1832	Use 1913	-
1835	Electrode Seal	0.95
1836	Use 20033533	-
1837	Ignition Box	136.46
1838	Spark Electrode with lead	16.88
1839	Gas Pipe (requires 1840 too)	11.68
1840	Pipe (requires 1839 too)	15.40
1841	Use 01005245	-
1842	Hood Assembly	20.25
1843	Air Baffle (Left)	2.91
1844	Air Baffle (Right)	1.07
1845	M15 to Pump Wiring	6.91
1846	Pipe	23.64
1847	Pipe	12.22
1848	Pump Pipe replaced 10023195	16.22
1849	Obsolete - Pipe	-
1850	Expansion Vessel Pipe	8.31
1851	Use 10021951	-
1852	Door Panel	11.68
1853	Use 10024528	-
1854	Use 10024558	-
1855	Use 10021849	-
1856	Obsolete - Cover	-
1857	Pressure Gauge	15.25
1858	Green to Red LED	7.14
1859	Temp control knob HTG&DHW	3.30
1860	DHW/HTG Mode selector switch	3.30
1861	Cap	0.84
1862	Spring	1.83
1863	Use 10023044	-
1864	Clip	4.94
1865	Adhesive Film	1.92
1866	Adhesive Film	1.66
1867	Pin/Screw for Control Panel	1.54
1868	Obsolete - O Ring	-
1869	O Ring	0.26
1870	M12 to Fan Wiring	22.28
1871	Wiring M3 to Primary thermistor, High limit stat & AP Switch	32.25

SPARE PARTS

Part No.	Description	Price
1872	Wiring M5 to DHW thermistor, Boiler flow switch & DHW Flow switch	41.63
1873	Wiring M11 to Motorised valve	9.69
1874	Wiring to CVI - M4 & M14 to Gas valve, Mod coil & ign box	29.63
1878	Use 1549	-
1879	Use 1531	-
1880	Case	111.37
1881	Locating Clip R/H	1.74
1882	Locating Clip L/H	1.74
1888	Water supply stop cock	17.28
1890	Clip	0.63
1895	Terminal Board	3.99
1901	Obsolete - Clip	-
1910	Obsolete - Expansion Vessel Pla	-
1912	Use 2073	-
1913	Guard Replaced 1832	6.80
1914	Use 01005246	-
1915	Obsolete - Fan Baffle	-
1916	Obsolete - Fan Baffle	-
1917	Use 10023202	-
1918	Obsolete - Pipe	-
1919	Use 10022015	-
1920	Use 10020217	-
1922	Obsolete - Case	-
1931	Use 1838	-
1947	1AM Fuse (Individual)	1.16
1955	Expansion Vessel	64.85
1956	Flow governor (Pink)	4.12
1957	Domestic Heat Exchanger	124.15
1959	Combustion Chamber	66.39
1960	Obsolete - Burner	-
1964	Electrode	17.26
1966	Gas Pipe	15.75
1967	Obsolete - Main Heat Exchanger	-
1968	Hood Assembly	41.69
1969	Obsolete - Combustion Chamber Assembly	-
1970	Obsolete - Combustion Chamber Cover	-
1971	Air Baffle	2.50
1972	Obsolete	-
1973	Front Panel	9.94
1974	Back Combustion Panel	9.94
1975	Pipe	26.07
1978	Obsolete - Vokera Logo	-
1979	Obsolete - Trade Mark Label	-
1980	Clock Wire	7.35
1987	Distribution Manifold	326.01
1988	Heat Exchanger Jacket	5.43
1996	Control Panel Flap	14.16
18700005	Washer	12.62
20000118	Drain plug	10.63
20000120	Flange for fan	17.59
20000121	Rear instrument panel	11.72
20000122	Casing	84.23
20000123	Conveyor	44.01
20000124	Instrument panel	18.80
20000125	Gas pipe	11.99
20000126	Use 20020255	-
20000127	Pipe	27.11
20000128	Pipe	35.88
20000129	Air bleeding connection Pipe	7.28
20000130	Spring clip	2.08
20000131	O Ring	0.89
20000132	Flexible pipe	5.83
20000133	Flexible pipe	5.92
20000134	Pump cable	7.08
20000135	Combustion cable	17.09
20000136	CN1 to M3A, M3 and Fan	22.74
20000137	Gas valve cable	13.65
20000138	CN2 to Ignition Transformer	8.28
20000140	Air box side	21.87

SPARE PARTS

Part No.	Description	Price
20000141	Condensing exchanger Assembly	460.12
20000142	Top flue outlet blanking cap	4.97
20000143	Drain plug	21.42
20000148	Burner	104.76
20000168	Instrument panel	18.80
20000498	Use 20007052	-
20000533	Cock	4.55
20000539	Clip	0.37
20000692	Insulation Panel	2.64
20000713	Detector Replaced 20075973	4.94
20000761	Cover	14.40
20000762	Wiring X2 to M4 (OT & external sensor)	9.57
20000763	Pump cable	18.73
20000764	Low tension cable	12.53
20000765	Combustion cable	26.45
20000767	Gas valve cable	13.42
20000768	CN1 to Fan, Fused block and Controls block	22.62
20000769	Pipe	10.23
20000773	Instrument panel	15.37
20000774	Door Panel	3.61
20001003	Protection	10.50
20001101	Instrument panel cover Rep 10027549	9.82
20001102	Instrument panel	18.34
20001103	Instrument panel	12.33
20001116	Use 20008307	-
20001126	Instrument panel - If rep 10023933 - change fascia components as well	46.90
20001140	Instrument panel	44.14
20001141	Instrument panel	41.11
20001560	Ignition cable	19.99
20001563	Use 20002969	-
20001564	High limit stat (With Clip)	17.66
20001617	Combustion fan cable	36.45
20001681	CN1 to Fan Power Supply, CN2 to Ignition Transformer	24.24
20001873	Use 20002906	-
20002045	Ignition Cable	10.68
20002906	Pump rep 2225 & 20001873	162.92
20002969	Ignition transformer with wires Rep 10026237 & 20001563	34.99
20002995	Fan	212.38
20003181	Water pressure switch - Replaced 10028141	8.41
20003819	Use 20081926	-
20004365	Use 20081926	-
20004832	Use 10027352	-
20004978	Use 10027352	-
20005146	Use 20052572	-
20005150	Use 10021419	-
20005151	Use 10023661	-
20005205	Control Panel	32.55
20005544	Heat exchanger	302.00
20005546	Spring Clip	3.74
20005549	Cap smoke analysis	7.53
20005550	Plug	0.95
20005551	NG burner	24.43
20005552	Washer	1.19
20005553	Gas pipe	20.38
20005554	Gas pipe	11.26
20005556	Pipe	12.03
20005557	Pipe	12.52
20005558	Pipe	16.91
20005559	Pipe	13.66
20005560	Front insulation panel	6.54
20005561	Back insulation panel	6.71
20005562	Insulation panel	9.62
20005566	O Ring	1.91
20005568	Heating distrib.	6.89
20005569	Printed circuit board MP08	97.46
20005571	Low tension cable	19.98
20005572	Use 20035405 Wiring Harness CN2 to M3 mains connection, pump & gas valve	-
20005574	Cover	5.70
20005575	Knob	1.70

SPARE PARTS

Part No.	Description	Price
20005579	Knob	1.42
20005580	Quick primer pressure gauge	10.37
20005582	Pump	138.42
20005584	NG Burner Injector Manifold	14.37
20005585	High limit stat	2.63
20005586	Plastic Hole cover	1.34
20005591	Frame	23.58
20005594	Combustion chamber cover	29.90
20005595	Kit cable grommet	5.61
20005596	Flue draught diverter	7.57
20006403	Condensing level detector cable Replaced 10024121	11.77
20006411	Fan baffle	7.43
20006423	Casing	86.44
20007047	Heat Exchanger Jacket	1.70
20007050	Flue sensor	11.75
20007052	Main Printed circuit board	320.86
20007053	Conveyor	46.17
20007057	Heat exchanger jacket (Rep 1807)	2.80
20007692	Cover	56.63
20007783	Heating by-pass valve	1.88
20007784	Gas valve	81.90
20008306	Conveyor Replaced 10028536	34.99
20008307	Main Printed circuit board	175.90
20008788	Sonda Di Temperatura	30.51
20010331	Condensing Pipe	4.37
20010682	Pump 32-80	340.67
20011042	Clip	0.74
20011043	Connection	5.92
20011048	Fumes connection	11.04
20011082	Instrument panel	17.38
20011392	Casing cover	45.33
20011393	Case Assembly	129.64
20011402	Pump	160.07
20011403	Gas cock	29.72
20011411	Frame Assembly	67.94
20011419	Use 20052578	-
20011420	Pipe	24.51
20011421	Pipe	14.54
20011422	Pipe	11.31
20011423	Pipe	16.05
20011424	Printed circuit board	105.82
20011443	Printed circuit board Kit	36.40
20011449	CN8 - J1 Display Wiring Harness	3.43
20012544	Low tension cable	7.65
20012937	Flexible Pipe	6.89
20012949	Frame Assembly	58.07
20013055	Knob	1.73
20013140	Pipe	9.74
20013349	Combustion cable	22.92
20013350	Low tension cable	10.20
20013352	LED light guide	0.68
20013353	Pipe	23.01
20013354	Ignition transformer	12.24
20013582	Front Insulation Panel	3.78
20013583	Back Insulating Panel	3.74
20013968	DHW Actuator	18.88
20014025	Control Knob	1.73
20014074	Connection	6.27
20014873	Pipe	14.15
20014882	Water gauge carrier	1.61
20014884	Light guide	1.29
20014885	Pressure gauge	16.68
20014887	Heating Control Knob	1.54
20014888	Hot Water Control Knob	4.49
20014891	Instrumental panel	14.29
20014920	Frame	39.11
20015932	Mixer Replaced 10024295	33.94
20016279	CN2 to Water Pressure Switch, Flow meter & DHW NTC	14.02
20016280	Ignition Flame Wiring Harness J13 to flame sensor, CN1 to flow/return NTC's, J12 to flow overheat stat, J24 to fan (LV) & J7 to condense/ flame sensor	24.48
20016282		33.92

SPARE PARTS

Part No.	Description	Price
20016283	Printed Circuit Board	262.53
20016328	Burner Assembly	110.34
20017585	Metal Combustion Chamber Cover	9.61
20017591	Pipe	32.53
20017592	Pipe	34.81
20017594	Actuator/Motorised valve	49.39
20017596	CN4 to Motorised Valve	30.62
20017597	Use 20043594	-
20017598	Square Locking Pin	1.19
20017599	Valve with cartridge	71.01
20017785	Hanging bracket	7.17
20017899	Detector	9.07
20018986	Casing	75.72
20019250	Casing - Unica 32HE & 36HE	132.68
20019506	LPG to NG Conversion Kit	11.03
20019507	NG to LPG Conversion Kit	18.48
20019763	Pipe	10.73
20019764	Pipe	22.39
20019765	Pipe	17.80
20019766	Air bleeding connection Pipe (Rep 10028516 & 10028515)	10.43
20019767	Locking Pin	0.37
20019768	Auto air vent (Black)	4.97
20019769	Flow Pipe Assembly (Rep 10029457)	63.55
20019888	Air Separator	15.08
20020178	Air bleeding connection Pipe	4.67
20020179	Flow Pipe Assembly Rep 10029458 & 10027318	64.24
20020181	Air bleeding connection Pipe	5.44
20020182	Flow Pipe Assembly (Rep 10029515)	63.45
20020192	Pipe	16.02
20020252	Pipe	18.65
20020254	Pipe	10.17
20020255	Flow Pipe Assembly replaced 20000126	57.80
20020300	Frame Assembly	85.48
20020309	45mm restrictor ring rep.10024037	2.37
20020310	Flue flange Ø 47	2.94
20020311	Flue flange Ø 43	2.94
20020377	42mm restrictor ring	2.37
20020899	Pipe	45.38
20020900	Pipe	77.13
20021032	Combustion cable	28.71
20021496	3 Way Heating Manifold & Cartridge	67.20
20021497	3 Way Manifold & Cartridge	58.74
20021548	Pressure connection	1.05
20021597	Fan support Kit	4.26
20022564	CN5 to Pump & 3 Way Valve motor	23.95
20023928	Fixing flange	1.17
20024086	Spring Clip	3.97
20024202	Pump Cable	24.74
20024205	Printed Circuit Board	31.14
20024206	Hydraulic control cable	35.44
20024419	Use 20029826	-
20024559	Pressure Transducer	27.14
20024591	Condensing Exchanger Assembly	374.66
20024600	Gas Pipe	15.03
20024841	3-Way Valve Motor	28.48
20024869	O Ring	0.63
20025687	Signal amplifier	1.91
20025733	Siphon	9.40
20025734	Use 20113021	-
20025735	Use 20069541	-
20025736	CN1 to Ign Transformer, CN3 to Fan, CN10 to Fan & CN11 to Flow/Return NTC's, Flue NTC & High Limit Stat	55.53
20025737	Ignition electrode with Lead	17.09
20025738	Electrode	11.80
20025740	Seal for Ignition electrode	0.89
20025743	Pipe	6.00
20025744	Flow Pipe Assembly	39.87
20025745	Pipe	24.16
20025746	Air bleeding connection Pipe	8.06

SPARE PARTS

Part No.	Description	Price
20025747	Washer	0.26
20025752	Use 20039202	-
20025753	Washer	3.15
20025755	Copper Pipe from Safety Valve	9.03
20025756	Copper Tail 15mm	5.66
20025757	Copper Tail 22mm	6.64
20025758	Copper Pipe (L Shape)	7.42
20025760	Suction pipe	4.94
20025761	Mixer	17.66
20025762	Use 20039953	-
20025763	Pipe	26.58
20025764	Pipe	18.73
20025765	Use 20039923	-
20025880	Pump	262.53
20025881	Pipe	26.33
20025883	J9 to divertor actuator & M2 (secondary pump)	19.58
20025884	Pump Cable	13.36
20026048	Compact 25A Instrument Panel	12.16
20026049	Outlet nut	4.58
20026051	Diaphragm	4.01
20026055	Control Panel Cover	19.14
20026056	Flue collector	6.23
20026058	Test Point Cap	2.77
20026059	Washer	2.77
20026060	Conveyor	52.91
20026061	Complete Burner Assembly	160.82
20026073	Casing	66.84
20026079	Burner Assembly	200.24
20026080	Compact 29A Instrument Panel	11.14
20026081	Use 20039924 Exchanger Assembly	-
20026082	Diaphragm	3.78
20026083	Mixer	16.91
20026585	Control panel	130.52
20026586	Use 20039202	-
20026587	Wiring J3 to M3 230v mains connector & M6 connector block (TA link)	14.87
20026589	Casing	101.37
20026724	Fan Kit	47.65
20026728	Fixing flange	2.50
20028324	NG burner	28.84
20028325	Collector	19.53
20028661	CN4 to divertor actuator	13.57
20028731	Safety Valve	12.85
20028732	Pipe	43.02
20028733	Pipe	40.17
20028734	Pipe	101.56
20028736	Pipe	11.53
20028737	Washer	2.50
20028738	Pipe	27.72
20028739	Conveyor	59.14
20028740	Pressure Switch	58.51
20028741	Mixer	56.51
20028742	Washer	2.85
20028744	O Ring	1.48
20028745	Stub Pipe	32.80
20028746	Washer	7.12
20028747	Stub Pipe	83.08
20028748	Cover	57.53
20028749	Pipe	17.71
20028750	Pipe	46.02
20028752	Pipe	158.99
20028759	Suction Pipe	71.46
20028760	Flexible Pipe	4.99
20028761	Flexible Pipe	4.06
20028762	NG Injector	6.81
20028763	Burner Assembly	95.68
20028765	Condensing Exchanger Assembly	418.13
20028769	Cover	48.66

SPARE PARTS

Part No.	Description	Price
20028776	Case Assembly	42.17
20028780	Knob	1.85
20028781	Expansion Vessel	63.59
20028782	Frame	53.35
20028783	Quick Primer pressure gauge	11.42
20028904	Nipple	38.85
20028963	PCB Replaces 10028996 & 10024554	177.75
20029043	LPG to NG Conversion Kit	9.79
20029052	LPG to NG Conversion Kit	7.12
20029055	Use 20113110	-
20029826	Expansion vessel Rep 20024419	83.57
20029985	DHW Actuator	22.26
20030209	Venturi Kit (Repl 01005405)	20.02
20030334	Airbox	48.78
20031414	LPG to NG Conversion Kit	20.34
20031415	LPG Conversion Kit	24.26
20031497	Mixer (Red)	80.58
20031569	Use 20030209	-
20032150	LPG to NG Conversion Kit	11.87
20032155	NG to LPG Conversion Kit	11.87
20032553	Use 20019888	-
20033722	Tank Condensation Collecting	13.66
20034037	3 way htg manifold with cartridge (10026508) & motorised valve (20024841) Complete	65.97
20034320	Expansion Vessel	75.42
20035019	Air Vent bottle	19.40
20035390	Pipe	24.96
20035391	Gas pipe	22.73
20035392	Cover Assembly	6.18
20035393	Pipe	12.11
20035394	Cock	14.60
20035397	Case Assembly	75.64
20035404	CN9 to DHW Flow Switch, DHW NTC & Water Pressure Switch	22.70
20035405	CN2 to M3 Mains Connection, Clock Harness, Pump & Gas Valve (With Tyco lead) RePLACED 20005572	50.42
20035501	Instrumental panel	12.11
20035502	CN9 to Water pressure switch	16.96
20035533	Gas valve - Replaced 10020574 & 10021021	132.55
20035608	Control panel	12.11
20035609	Pipe	11.84
20035613	Case Assembly	95.27
20035648	Filling Cock Knob	1.92
20035649	Filling Cock	5.26
20035912	Cover	32.13
20036112	Pump	152.05
20036120	Pipe	8.73
20036537	Tryton Retarder	2.49
20036547	Use 20115425	-
20036548	Flow Switch	68.58
20036549	Use 20104238	-
20036551	Inlet Water Pipe	197.69
20036552	Outlet Water Pipe	108.93
20036553	Compressor	389.30
20036554	Compressor Protection Module	6.05
20036555	Condenser	476.06
20036556	Inverter Module	467.96
20036564	Use 4026256	-
20036581	Inverter Module	492.18
20036582	Outlet Water Pipe	104.88
20036583	Condenser	907.73
20036585	Straightner	32.26
20036586	Liquid Assy	161.39
20036587	Condenser	1,230.45
20036588	Front Panel	114.98
20036607	Motor	139.19
20036608	Condenser	1,654.05
20036609	Compressor	1,512.87
20036610	Accumulator	14.10
20036611	Magnetizing Coil Valve	27.86
20036612	4 Way Valve	125.08
20036613	Logical PCB	459.91

SPARE PARTS

Part No.	Description	Price
20036614	Liquid Assy	181.55
20036630	Thermostat	318.72
20036700	External probe	52.46
20036990	Mixer Spacer	0.63
20038366	CN2 to Water Pressure Switch, Flow meter & DHW NTC	26.95
20038577	Unica i (Non-ErP) Air box	78.75
20038597	Combustion Chamber Cover	29.82
20039151	Pipe	19.53
20039152	Pipe	18.03
20039153	Pipe	9.40
20039202	Gas valve Rep 10028538 & 10027187 & 20025752	141.12
20039204	Gas Diaphragm	7.93
20039359	Glass Kit	54.90
20039402	M6 to CN6 & CN5	23.74
20039923	Exchanger Assembly rep 20025765	265.57
20039924	Exchanger Assembly rep 20026081	282.51
20039926	Pump Kit	163.86
20039953	Flow Connection for Compact A	4.22
20039954	Return Connection for Compact A	4.22
20040102	Flue drain connection	8.59
20040474	Gas Pipe	12.52
20040675	Gas Valve Solenoid (Fits 20039202/20035533)	65.94
20040979	Cock	28.48
20040980	CN2 - Mains terminal block, Pump, Water pressure switch & Gas valve Wiring Harness	100.52
20040981	CN4 - M3A Wiring Harness	23.95
20040982	CN1 - Ign transformer + FA1 Wiring Harness	23.95
20040983	CN10 - Fan Wiring Harness	19.14
20040984	CN9 - Water Pressure Switch + Cylinder Stat	23.95
20040985	Instrument panel	22.54
20040986	Pipe	15.42
20040987	CN3 - Fan Wiring Harness	33.51
20040988	CN11 - High limit, Flow NTC, Return NTC, Flue stat, UFH stat & FA2 - Flame sensor Wiring Harness	71.83
20040989	CN6 - M6 Wiring Harness	33.51
20040990	Pump	186.29
20040999	Frame Assembly	201.72
20041000	Case Assembly	138.83
20041049	Case	90.65
20041051	Fixing Door	5.26
20041053	Instrument Plate	11.96
20041058	Diaphragm	1.05
20041473	Diaphragm	1.00
20042113	Knob	1.70
20042114	Knob	1.70
20042115	Pressure gauge	13.57
20042121	Use 20060938	-
20043496	By-pass valve	1.92
20043523	Ionisation Electrode	11.87
20043524	Burner Assembly 25 kW (Ceramat)	154.26
20043594	3 way valve cartridge Rep 20017597	38.43
20043658	Front Right Panel	212.63
20043659	Front Casing	183.75
20043820	Use 20044364	-
20044364	Safety valve Rep 10025055 & 20034917 & 20043820	18.86
20044890	Lateral insulation panel	11.30
20044892	Burner 25 kW (Ceramat) and top gasket (20116624)	97.47
20044894	Burner Gasket	10.17
20044895	Exchanger cover	28.26
20044896	Burner	79.11
20045328	Use 20020179	-
20045568	LPG to NG Conversion Kit	18.08
20045569	NG to LPG Conversion Kit (3.9)	20.77
20046189	Water Pressure Switch Replaced 2214	24.95
20046265	Washer	11.53

SPARE PARTS

Part No.	Description	Price
20046269	Burner (New type Worgas)	109.62
20046270	Protection	10.51
20046560	Pressure switch same as 2726?	14.70
20046652	Panel	167.35
20046835	Flange and Insulation	24.86
20046836	Tryton with 3 Screws	18.25
20046837	Flange and Insulation	27.12
20046839	Tryton and Screws	14.18
20047573	Flue gas flange	33.90
20047802	Washer	1.47
20047807	Burner Flange	14.86
20047811	Ring Closing	4.18
20047812	Insulation	16.96
20047819	Washer	1.05
20047820	Sealant	15.26
20048263	Heat Exchanger shell	65.26
20048269	Heat Exchanger shell	54.69
20048271	Container Exchanger	58.77
20048272	Exchanger shell	81.36
20048322	Case Assembly	66.84
20048779	3 way valve	302.09
20049127	Exchanger	948.07
20049604	NTC Sensor	52.94
20049606	Plug/Hole Cover	2.88
20049608	CondexaPro Flue Stat adaptor cable	24.12
20049611	PCB Kit	75.21
20049613	Spark/Ignition Electrode	6.10
20049617	Quick primer pressure gauge	14.70
20049618	Frame Assembly	36.16
20050373	Low Tension Cable	33.98
20050374	Cover Assembly	11.61
20050376	Door Panel	4.18
20051029	Use 20101332	-
20051418	Heat Exchanger Support Bracket	9.09
20052519	Gas Pipe	6.30
20052572	Main Heat Exchanger Replaced 20005146 & 10023651	262.38
20052578	Main Heat Exchanger Replaced 20011419	245.62
20055213	NG Jet	12.43
20055216	Burner 29kW (Original Ceramat) and top seal (20116625)	100.01
20055396	Use 20109417	-
20055453	Conveyor	36.16
20055454	Use 20069541	-
20055455	Timer/Display Module	99.45
20057326	Control Panel Cover (Rear)	5.93
20057328	Case Assembly	58.91
20057330	Knob	3.96
20057331	Front Panel	15.71
20057332	Wiring Harness CN8 to M2 to Clock & CN5	10.17
20057346	Front Panel	14.25
20057350	LED light guide	2.82
20057351	Front Control Panel	14.70
20057394	Combustion wiring	27.56
20057395	Low tension wiring - ErP	12.76
20057751	Use 20113104	-
20057833	Frame Assembly	88.32
20057834	Case Assembly	108.49
20057837	Front Panel	39.55
20057854	Condensing exchanger Assembly	384.23
20057855	Gas Pipe	26.39
20057856	Use 20119995	-
20057857	Use 20119996 Detection electrode	-
20057858	Tryton	20.34
20057859	Pipe	30.96
20057861	Pipe	35.60
20057862	Pipe	36.84
20057864	Pipe	29.95

SPARE PARTS

Part No.	Description	Price
20057865	Pipe	63.28
20057866	Pipe	56.50
20057868	CN9 to DHW flow switch, DHW NTC & Water pressure switch	14.30
20057870	Washer	2.49
20057871	Washer	2.26
20057872	Glass Fibre	3.49
20057873	Flow Pipe Assembly	56.50
20057874	CN1 to ign transformer, CN3 to fan.	23.00
20057875	CN2 to M3 mains connection, clock harness, pump & gas valve + 3 core fly lead	57.63
20057876	CN10 to fan & CN11 to flow/return NTC's, Flue NTC & high limit stat	35.04
20057878	Washer	4.23
20057880	Conveyor	18.93
20057882	Top flue outlet blanking cap	21.76
20057885	Air/gas manifold	11.87
20057887	Burner Assembly	91.54
20057889	Washer	1.35
20057895	Hanging Bracket	5.66
20057896	Support Kit	50.86
20058630	Use 20123398	-
20058631	Front Panel	37.75
20058633	Burner Assembly	90.41
20058634	Pipe	58.20
20058635	Pipe	38.36
20058636	Support Kit	15.48
20059926	Use 20042114	-
20060133	Frame Assembly	29.77
20060559	Slave wiring harness	246.96
20060560	Power wiring harness	86.94
20060561	Slave PCB	439.24
20060564	Ignition cable	86.93
20060566	Ignition electrode	78.63
20060569	Fan	631.41
20060571	Gas valve	388.08
20060573	Connector	86.94
20060574	Delivery manifold	160.42
20060575	O Ring - Obsolete	18.31
20060598	Cock	132.30
20060601	Hose	120.17
20060676	Clip	13.72
20060677	Clip	14.99
20060679	Gas pipe	45.76
20060682	O Ring	18.31
20060685	Connector	109.81
20060687	Temperature probe	73.22
20060689	Pipe	45.77
20060691	Pipe	27.46
20060692	Connector	128.12
20060694	Connection	54.90
20060695	Cable connector	45.77
20060696	Guard	18.31
20060697	Elbow	32.04
20060717	Baffle	9.45
20060718	90° bend	160.13
20060725	Cock	215.03
20060727	Master PCB	416.37
20060728	Master wiring harness	132.68
20060729	Burner	173.85
20060730	Burner seal	68.63
20060731	Use 20101605	-
20060732	Flange	114.40
20060938	Card Reader Kit	50.86
20061168	Combustion Chamber Clip and 2 rivets	1.92
20061473	Gas manifold	439.24
20061474	Delivery manifold	754.94
20061475	Lateral panel	251.65
20061476	Rear panel	320.29
20061477	Heating return manifold	741.22
20061478	Upper Front Panel	173.85
20061480	Top panel	123.53
20061481	Lateral panel	239.67

SPARE PARTS

Part No.	Description	Price
20061482	Left Panel	251.65
20061484	Right Panel	439.24
20061486	Upper Front Panel	667.99
20061488	Top Panel	59.49
20061489	Gas manifold	311.12
20061490	Heating return manifold	507.86
20061492	Delivery manifold	517.01
20061493	Connector	22.87
20061494	Connector	22.87
20061498	O Ring	13.72
20061501	Bend	45.77
20061502	Rear panel	68.63
20061504	Diaphragm	13.72
20061506	Flange	36.59
20061507	Top Panel	585.64
20061508	Top Panel	585.64
20061510	Left Hand Door	704.62
20061512	Right Hand Door	667.99
20061513	Left Panel	283.66
20061514	Rear Panel	301.98
20061516	Right Panel	283.66
20061517	Top Panel	338.56
20061518	Rear Panel	311.12
20061751	Thermometer	33.79
20061944	Use 20029826	-
20063116	4 Pole Connector	6.17
20063463	Siphon	7.23
20063464	Siphon Cover	5.21
20063466	Condensing Pipe	6.16
20063467	Condensing Pipe	5.78
20063468	Washer	1.05
20063584	Air Pressure Switch	21.08
20063990	Left Hand Door	704.62
20063991	Left Panel	462.11
20066456	Plastic Condense Pipe Replaced 10027543	21.98
20066460	Plastic Condense Pipe Replaced 10027568	23.09
20066463	Plastic Condense Pipe Replaced 10028015	21.48
20066464	Plastic Condense Pipe Replaced 10027977	23.74
20067062	Wiring Harness CN6 to M6 to CN5	29.04
20067270	Heat Exchanger	153.30
20067305	Heat Exchanger	205.07
20067310	Combustion cable	45.89
20067421	Front Panel	141.27
20067579	Mixer	73.46
20067580	Pipe	25.87
20067581	Flexible Pipe	14.70
20067584	Mixer	74.03
20067585	Gas Pipe	14.70
20067807	Instrument Panel	14.25
20067812	Instrument Panel	13.39
20067813	NTC Sensor	6.22
20067815	Use 20028733	-
20067816	Pipe	46.02
20067826	Pipe	158.99
20068881	Plastic Condense Pipe Replaced 10024132	20.50
20068882	Plastic Condense Pipe Replaced 10024440	21.32
20068884	Plastic Condense Pipe Replaced 10024521	22.17
20068965	By-Pass Valve Lock	1.25
20068999	Washer - Obsolete	1.25
20069007	Air Chamber Access Panel	41.53
20069510	Frame Assembly	113.01
20069541	Printed circuit board Replaced 20055454 & 20025735	130.53
20069542	3/4 Connection	6.11
20069549	Wiring Harness	43.31
20069587	LPG to NG Conversion Kit	33.90
20069592	LPG to NG Conversion Kit	33.90
20069593	NG to LPG Conversion Kit	33.90
20069786	DHW Actuator	8.39
20071334	Printed Circuit Board with display	107.36
20071802	Use 20101178	5.76
20071908	Gas Pipe	29.95

SPARE PARTS

Part No.	Description	Price
20071909	Flow Pipe Assembly	59.90
20071910	Flow Pipe	33.90
20071911	Frame Assembly	101.70
20071912	Air box front cover	42.95
20071914	Burner Assembly	58.77
20071916	Support Kit for Condensing Exchanger	11.87
20071918	Case Assembly	101.70
20071921	Condensing Exchanger Assembly	360.50
20072077	Sensing electrode	8.19
20072084	Cover	12.10
20072228	Knobs Kit (2 Knobs)	1.26
20072330	Pipe	23.81
20073417	Heat Exchanger	3,761.73
20073427	Flange	18.31
20073436	Fumes Connection	96.09
20073521	Control Panel	13.57
20073523	Case Assembly	67.81
20073678	Control Panel	13.57
20073700	Use 10022349	-
20073721	Control Panel	13.57
20073763	Condensing Assembly - Same as 20028765	418.13
20074451	Condensation Outlet Manifold	164.71
20074453	Exhaust Tube	103.36
20074454	Condensation Outlet Tube	18.31
20074458	Condensation Outlet Manifold	105.22
20074462	Exhaust Tube	105.22
20074728	Spark/Ignition electrode Replaced 10027620	17.80
20075973	Use 20000713	-
20076437	CN5 to Relay Board	2.04
20076889	Flexible Pipe	4.41
20076890	Combustion Cable	49.16
20076891	Flow Pipe Assembly	14.12
20076892	Front Panel	13.57
20076893	Case Assembly	82.11
20076998	Mixer	71.20
20078170	Front Panel	14.70
20078171	Pipe	30.60
20078173	Case Assembly	107.36
20078350	Use 20081926	-
20078519	Instrument Panel	17.80
20079833	Frame Assembly	113.01
20079944	Printed Circuit Board - Replaced 20036547	167.43
20081059	Plug - Obsolete	0.58
20081316	Fan Assembly with Built in Mixer	212.38
20081318	Fan Assembly with Built in Mixer	212.38
20081537	Air Box	39.55
20081858	Slave Wiring Harness	201.31
20081859	Motor	343.15
20081860	Pipe	100.67
20081926	Thermistor/NTC Replaced 20003819 and 20004365	13.95
20081973	CN7 TO CN2 External Pump Relay	19.16
20082101	Use 10025647	-
20082414	Connection	8.66
20082915	LPG to NG Conversion Kit	13.02
20082917	NG to LPG Conversion Kit	12.69
20083194	Case	75.13
20083225	Heat Exchanger	153.76
20083256	Pipe - Obsolete	21.95
20083257	Pipe - Obsolete	13.23
20083995	LPG to NG Conversion Kit	38.42
20083996	NG to LPG Conversion Kit	40.69
20084372	Fan Baffle R/H	6.78
20084373	Fan Baffle - Replaced 10020516	3.15
20085616	LPG Conversion Kit - Obsolete	14.18
20085965	Fan	264.59
20086250	Burner	46.84
20086269	Heat Exchanger Insulation	7.17
20086438	LPG to NG Conversion Kit	38.86
20086673	Burner	58.77
20087082	Combustion Cable	41.35

SPARE PARTS

Part No.	Description	Price
20087173	NG to LPG Conversion Kit	66.15
20087176	NG to LPG Conversion Kit	66.15
20087319	Burner	77.32
20087321	Mixer	75.66
20087361	Frame Assembly	130.20
20087379	Burner	38.99
20088612	Unica 1 (ErP) Air box	78.75
20088617	Instrument Panel	14.06
20088621	Instrument Panel	14.06
20089382	High head pump	179.43
20089999	Plug and Nut	2.12
20090680	Pipe	16.76
20091280	Fumes Thermostat	2.95
20091281	NG Burner	42.57
20091282	Flue draught diverter	30.36
20091526	Pipe	14.76
20091527	Pipe	10.64
20092620	Fitting / Union Replaced 10026194	4.55
20093799	Clip for High Limit stat onto Heat Exchanger	4.77
20093908	Integral NRV	9.92
20094369	Gas Valve	61.82
20095477	Casing	124.58
20096202	Degasser Connection Assembly	3.31
20096531	Wiring Harness ErP	34.99
20096793	Degasser Connection Assembly	3.31
20097247	Instrument Panel	25.20
20099105	ErP Pump Assembly	294.37
20099541	Fairlead	3.27
20099544	Pipe	15.67
20099545	Flow Pipe	17.86
20099548	Degasser Kit and Pipe	38.08
20100735	Pump Cable ErP	10.67
20100812	PWM Pump Cable	10.63
20101177	Instrument Panel	13.72
20101178	Control Panel Cover (Rear) Replaced 20071802	6.37
20101179	Instrument Panel and Cover Combined	18.90
20101312	Use 5221	-
20101331	Flange Assembly - Replaced 20047573	33.36
20101332	Heat Exchanger Bracket - Replaced 20051029	6.00
20101605	O Ring replaced 20060731 CN2 TO M3 Mains Connection, Pump & Gas valve with TYCO lead for clock	2.36
20101723	Pressure Gauge Holder	36.14
20101724	Pressure Gauge	1.46
20101725	Pressure Gauge	13.44
20102262	PTFE teflon gasket Replaced 105904 CN2 TO Gas Valve, Pump & Fuse block, also TYCO plug for OT controls	13.48
20102628	Flow Pipe	46.31
20102629	Flow Pipe	18.73
20102646	Flow Pipe	19.02
20102766	Power wiring harness	33.98
20104238	Heat Exchanger - Replaced 20036549	584.99
20104982	Instrument Panel	13.72
20104984	Pump Caple	10.38
20104985	Flow Pipe	40.73
20104986	Pipe	65.65
20104988	Flow Pipe	41.48
20104996	Pump	297.10
20104997	M3a to CN4 external pump relay, CN2 gas valve, pump, pressure dif switch	51.47
20108296	Water Gauge Carrier	6.90
20109416	Pump	807.19
20109417	Discharge Temp Sensor - Replaced 4026285 and 20055396	112.10
20112974	Instrument Panel	10.50
20112975	Flow Pipe	22.84
20113021	CN9 to DHW flow switch, DHW NTC & Water pressure switch - Replaced 20025734	11.31
20113104	LPG to NG Conversion Kit (5.1 Jet) - Replaced 20057751	7.35
20113110	NG to LPG Conversion Kit (3.9 Jet) - Replaced 20029055	19.14
20115159	Nipple	3.15
20115165	Printed Circuit Board	93.45
20115425	Printed Circuit Board - Replaced 20079944 and 20036547	167.43
20116624	Gasket for top of 25kW Burner(20044892)	6.20
20116625	Burner seal (On top of 20055216 burner)	7.35

SPARE PARTS

Part No.	Description	Price
20118530	Air Box Cover	20.27
20118573	Pipe	13.39
20118574	Pipe	14.39
20118575	Pipe	9.87
20118577	Frame Assembly	43.05
20118578	Power wiring harness	40.95
20118580	Spark Electrode Cable	3.99
20118582	Spark Sense Electrode	9.98
20118588	Instrument Panel	16.91
20118590	Case Assembly	47.25
20118917	Clock Casing	2.76
20118918	Clock Cable	9.08
20118919	Valve Cover (Excluding Clock)	12.08
20118920	Instrument Panel	10.71
20118921	Control Panel Cover	3.15
20118922	Case	49.88
20119367	Display Frame on Caseing	2.63
20119369	Case Assembly	47.04
20119995	Ignition electrode - Replaces 20057856 Sensing/Detection electrode - Replaced 20072077 and 20057857	11.30
20119996		8.19
20120828	Locking Pin	0.42
20120837	Frame - Replaced 01005496	59.85
20123398	Condensing Exchanger Assembly - Replaced 20058630	384.23
20125030	Condensing Assembly - Replaced 20071921	360.50
20125237	Condensing Exchanger Assembly - Replaced 20057854	384.23
20125261	Expansion Vessel Bracket	2.10
20125380	Pipe	42.72
2033	Transformer (Repl.10023478)	89.54
2044	Use 10028141	-
2047	Heating bypass valve	5.31
2051	Pipe	17.86
2052	Pipe	35.41
2053	Pump Pipe	12.38
2059	Air Box Side (Left and right the same)	20.20
2060	Air Box Side (Left and right the same)	20.20
2061	Use 10020430	-
2062	Obsolete - Case	-
2068	Obsolete - Baffle	-
2069	Burner Baffle	3.24
2072	Air Chamber	47.40
2073	Air box bottom (Rep 10027894/1912)	54.05
2074	Boiler Bracket	8.55
2075	Use 10022029	-
2076	Fan Assembly	136.46
2080	Use 10020493	-
2089	Electronic Ignition Box	152.57
2090	Gas Pipe	14.61
2091	Use 2470	-
2092	Sensing Electrode	11.61
2093	Pipe	33.99
2095	Obsolete - Pipe	-
2096	Obsolete - Wiring Harness	-
2111	LPG jet 5.0	11.05
2127	Insert	0.89
2139	Gas Valve (replaced 2897)	186.47
2164	Use 10023603	-
2165	Use 10027757	-
2192	Use 10027864	-
2201	Use 10022533	-
2204	8 Litre Expansion Vessel	80.64
2211	Potentiometer Extention	0.95
2213	Obsolete - Connection	-
2214	Use 20046189	-

SPARE PARTS

Part No.	Description	Price
2226	Rubber Seal	3.01
2228	Combustion Cover	5.97
2229	Use 10024779	-
2230	Rear Insulation Panel for Combustion Chamber	7.49
2231	Side Insulation Panel for Combustion Chamber	5.82
2232	Front Insulation Panel for Combustion Chamber	7.98
2233	Blanking Plate	3.01
2234	Burner	58.21
2235	Burner Bar NG	33.50
2236	Obsolete - Burner Bar LPG	-
2237	Connection	9.30
2238	Cross Lighting Strip	0.95
2243	Obsolete - Gas Valve Outlet Pipe	-
2255	Spark / ignition electrode and lead	20.79
2258	High Limit Thermostat	7.49
2260	Use 10022499	-
2261	Manifold Plug	3.06
2266	3/4" Gas cock	12.37
2294	Clock Harness (Option)	19.19
2310	Main Heat Exchanger	219.52
2353	NG Jet	12.43
2378	Use 01005246	-
2381	Use 01005245	-
2455	Screw Driver	0.74
2468	Pressure Gauge	17.21
2470	Spark Electrode	23.30
2490	Flexible Pipe	20.37
2491	Pipe	12.79
2492	Flexible Pipe	29.10
2493	Pipe	26.19
2494	Gas Pipe	14.55
2495	Wiring Harness	44.24
2554	M5 to Pump cable	12.99
2564	Pressure Gauge	29.64
2573	Expansion Vessel Rep 106333 10 Litre	89.00
2577	Obsolete - Cold Water Inlet Pipe	-
2578	Pipe	3.96
2586	44mm Restrictor Ring	1.16
2588	Clip	0.68
2600	Thermostat	22.01
2677	Air Pressure Switch	55.04
2678	Obsolete - Hood Assembly	-
2701	Ribbon Cable M9 to M2 between main PCB & display PCB	7.80
2703	Obsolete	-
2710	Fitting	4.56
2726	Water Pressure switch (10028141)	19.58
2776	Pipe	4.11
2785	Thermostat Shaft	2.16
2801	Burner NG	66.36
2802	Obsolete - Burner LPG	-
2803	Obsolete - Combustion Chamber Assembly	-
2804	Frame	60.93
2805	Pipe	29.26
2806	Obsolete - Mynute 28SE Wiring	-
2810099	Obsolete - Eclipse Heat Exchanger	-
2819	Combustion Cover	14.48
2820	Air Baffle RH	2.50
2821	Obsolete - Air Baffle LH	-
2822	45° Flow/Return Valve	22.08
2823	Flow / Return valves connector	9.56
2851	Obsolete -Thermostat Bracket	-
2860	Hood Assembly	38.67
2865	Fan Assembly	134.04
2868	Venturi	9.98
2873	Side Insulation Panel for Combustion Chamber	7.85
2888	Obsolete - Seal	2.22
2897	Use 2139	-
2903	DHW Inlet Manifold	16.22
2904	Use 10020335	-

SPARE PARTS

Part No.	Description	Price
2906	Motorised Valve Fixing Wrench	0.37
2907	Safety valve Replaced 8433 (Push Fit)	12.03
2908	Non Return Valve	2.19
2909	Valve For DHW Bypass	6.27
2910	3 Port Valve Bobbin	2.98
2911	Automatic by-pass plug	3.15
2913	Bobbin Seating Washer	1.40
2915	Distribution Manifold (Complete)	183.92
2916	Obsolete - Distribution Manifold	-
2936	Hood Assembly	25.53
2939	Fan Flue Connection	16.02
2940	Bracket	1.01
2946	Fitting/union	2.91
2950	Use 10021792	-
2966	Cover	0.37
3020233	Premix Burner	172.05
3020235	Fan	274.95
3020400	Burner head silicone gasket	10.85
3087	Obsolete - Venting Plug	-
3106	Obsolete - Fan Plate	-
3107	Obsolete - Clamp Bracket	-
3112	Obsolete - Pressure Differential Switch RS Turbo	-
3113	Obsolete - Pressure Socket & Venturi	-
3118	Obsolete - Electric Igniter Generator	-
3135	Obsolete - Seal	-
3139	Sight Glass	4.89
3175	Obsolete - Heating Manifold	-
3183	Obsolete - Auto By-Pass Connecting Tube	-
3190006	Neutro door sea 1 metre	5.85
3207	3 Port Valve	112.72
3208	Obsolete - Heating Manifold	-
3212	Heating Thermostat	27.94
3220043	Neutro pellet tank start	14.18
3260168	Neutro main pcb	163.32
3260169	Neutro flue temp probe	25.78
3260170	Neutro ambient temp probe	8.61
3260171	Neutro primary temp probe	15.05
3267	Heating Thermostat	17.80
3293070	Neutro on/off switch	29.62
3340181	Neutro worm screw motor	96.68
3387	Use 4188	-
3409	High Limit Stat	17.80
3412	Clip	0.79
3434	Obsolete - Fan Assembly	-
3464	Anti freeze stat	6.13
3478	3 Amp Fuse (individual)	1.70
3484	Obsolete - Burner Baffle Right Side RS Turbo	-
3497	Obsolete - Injector - Pilot	-
3499	Obsolete	-
35026	Obsolete - Combustion Chamber	-
3601205	Neutro fan	236.33
3601207	Neutro air pressure switch	42.12
3601500	Neutro ignition plug support bracket	2.09
3601505	Neutro display PCB	51.56
3607	Obsolete - Piezo Igniter	-
3611	Obsolete - Diaphragm 6 screw	-
3721	Obsolete - Ignitor Lead	-
3740	Obsolete - O Ring 4 Pumb Union	-
3771	Use 4961	-
3774	Obsolete - Main Burner Jet LPG 1.30	-
3800	Obsolete - Expansion vessel	-
394404	Unifix Clock Screw	0.02
4007	Sight Glass Retaining Ring	0.63
4008	Obsolete - Expansion vessel	-
4009	Obsolete - Main Heat Exchanger RS Turbo	-
4013	Obsolete - Gas Valve to Burner Connecting Pipe	-
4014	Obsolete - Main Heating Return Pipe	-
4016	Obsolete - Pilot Pipe	-
4026	3/4" BSP Locknut	1.14
4026225	Fan motor	60.25

SPARE PARTS

Part No.	Description	Price
4026226	Fan	20.78
4026229	Compressor	506.95
4026230	Anti-vibration feet	6.27
4026231	Accumulator	47.80
4026232	Liquid receiver	43.61
4026233	4 way valve	35.29
4026234	Liquid Assy	51.93
4026235	Magnetizing coil valve	18.69
4026236	Outlet water pipe	95.57
4026237	Inlet water pipe	151.69
4026239	Reactor	49.88
4026240	Condensing pipe	3.12
4026241	Expansion vessel	60.25
4026244	Heat Exchanger	625.35
4026245	Pump	251.40
4026246	Water sensor	64.38
4026247	Flow switch	68.58
4026248	Use 10029306	-
4026249	Pressure valve	29.11
4026250	Discharge temp sensor	6.27
4026251	Exchanger detector	4.14
4026252	Suction detector	4.14
4026253	External temperature detector	4.14
4026254	Anti-vibration feet	2.06
4026255	Inverter Module Rep 4026258	386.45
4026256	Front Panel	80.67
4026257	Heat Exchanger	1,371.29
4026258	Use 4026255	-
4026259	Compressor	565.10
4026260	Liquid Assy	62.35
4026261	Magnetizing Coil Valve	14.51
4026262	Liquid Receiver	62.35
4026263	Reactor	58.20
4026264	Liquid Receiver	112.22
4026265	Inlet Water Pipe	89.36
4026266	Compressor	1,371.29
4026267	Anti-Vibration Feet	6.27
4026271	Heat Exchanger	1,134.40
4026272	Detector	95.57
4026273	Detector	70.65
4026274	4 Way Valve	37.43
4026277	Fan	18.69
4026280	Printed Circuit Board	81.02
4026281	Inverter Module	484.12
4026283	Outlet Water Pipe	224.40
4026285	Use 20109417	-
4026287	Pump	376.04
4026291	Guard	36.31
4026292	Condenser	685.82
4026295	Transformer	15.82
4028	Use 6493	-
4036	Obsolete - Rubber Ring for 4018	-
4037	Obsolete - Seal	-
4039	Obsolete - Seal	-
4045	Obsolete - Summer/Winter Switch	-
4049	Obsolete - Double Microswitch	-
4061	Obsolete - Nut	-
4062	Obsolete - Olive	-
4065	Obsolete - 22mm Olive	-
4095	Obsolete - Hot Water Outlet Nut and Tail	-
4105	Obsolete - Electrode Lead	-
4114	Obsolete - Pump Union Nut	-
4144	Obsolete	-
4148	Triple Microswitch	24.92
4157	Obsolete - Triple Rocker Switch	-
4174	Obsolete - Hanging Bracket	-
4174A	Obsolete - Hanging Bracket	-
4175	Obsolete - PCB DC Turbo	-
4188	Obsolete - PCB	-
4189	Obsolete - Flow Pipe with Air Separator	-

SPARE PARTS

Part No.	Description	Price
4250	Safety Valve (Screw Fit)	11.28
4254	Automatic Air Vent	10.09
4254G	Auto Air Vent	10.09
4257	Obsolete - Boiler Thermostat	-
4274	Obsolete - 1/2 Inch BSP Locknut	-
4298	Diaphragm	4.98
4302	Microswitch	14.84
4321	Obsolete - See 01005137	-
4325	Obsolete - Cork Gasket	-
4332	Obsolete - Singel Microswitch Cover	-
4333	Obsolete - Main Heat Exchanger RS Turbo	-
4336	Obsolete - Main Burner	-
4357	Obsolete	-
4359	Obsolete - Double Rocker Switch	-
4426	Obsolete	-
4434	Obsolete - Resistor	-
4441	Temperature Gauge (rep 7171)	17.00
4449	Obsolete - Expansion Vessel Clamp Bracket	-
4472	Obsolete - Pressure Gauge	-
4489	Obsolete - Expansion Pipe	-
4490	Obsolete - Main Heating Return With Union	-
4492	Expansion Vessel	77.13
4493	Obsolete - Heating Distribution Manifold	-
4494	Obsolete - Domestic Distribution Manifold	-
4495	Obsolete - 3 Way Valve	-
4496	Obsolete - Pipe	-
4497	Obsolete - Cylinder Return Pipe with Union	-
4505	Obsolete	-
4518	Obsolete - Mini Expansion Vessel	-
4534	Obsolete - Flue Outlet Adaptor	-
4535	Obsolete - Gas Connecting Barrel	-
4537	Obsolete - Piezo Igniter	-
4538	Obsolete - Lint Guard	-
4539	Obsolete - Flow and Return Valve	-
4540	Obsolete - Cock	-
4541	Obsolete - Cock	-
4542	Obsolete - Boiler Thermostat	-
4543	Obsolete - Thermostat Control Knob 21/84 MCF	-
4544	Connection for Dom Exp Vessel	2.94
4545	Obsolete - Domestic Heat Exchanger	-
4546	Obsolete - PCB DC Turbo	-
4549	Domestic Heat Exchanger	172.05
4551	Obsolete - Cylinder Flow Pipe with Union	-
4559	Obsolete - NTC Probe	-
4562	Obsolete - Double Microswitch Cover	-
4563	Obsolete - Double Microswitch	-
4565	Obsolete - Boiler Thermostat	-
4573	Obsolete - Grey Main Frame	-
4577	Obsolete - Support Bracket for Front Panel	-
4580	Obsolete - Pilot Bridge	-
4581	Obsolete - Expansion Vessel Fixing Bracket	-
4583	Obsolete - Double Action Hinge	-
4585	Obsolete - Stainless Steel Sheild	-
4587	Obsolete	-
4605	Obsolete - Flow Pipe with Air Separator	-
4611	Blanking Plug for Heating Manifold	0.74
4612	Obsolete - Blanking Plug	-
4617	Obsolete - Sleeve	-
4619	Obsolete - Front Seal	-
4625	Obsolete - Gas Valve	-
4627	Obsolete - Gas Connecting Barrel	-
4628	Obsolete	-
4630	Obsolete - Burner	-
4632	Obsolete - Spark Electrode	-
4634	Obsolete - Pilot Pipe	-
4636	Obsolete - Lead for HT Piezo	-
4638	Obsolete - Burner Injector Manifold	-
4640	Gas Valve	174.03
4641	Obsolete - Terminal Cover	-
4642	Obsolete - Washer for Piezo Ignitor	-

SPARE PARTS

Part No.	Description	Price
4650	Obsolete	-
4659	Obsolete - LPG Burner	-
4663	Obsolete - Magnetic Mod Spring & Coil	-
4665	Obsolete - Main Gas Injector	-
4668	Obsolete - Spring for Gas Regulator LPG	-
4680	Obsolete	-
4681	Obsolete	-
4691	Obsolete - Domestic Cylinder Supply	-
4692	Obsolete - Domestic Cylinder Hot Water Outlet	-
4699	Obsolete - Brass Socket Heating Flow & Return	-
4716	Obsolete - Gas Valve to Burner Outlet	-
4723	Obsolete - Tail Plate Seal	-
4751	Obsolete	-
4761	Obsolete	-
4768	Obsolete	-
4801	Obsolete	-
4802	Obsolete	-
4803	Obsolete	-
4806	Obsolete	-
4807	Lock Nut	0.35
4828	Obsolete	-
48309	Clip	2.14
48310	Stud	2.37
48355	Screw	1.09
48381	Clip	0.72
48382	Screw - Replaced 100940	1.09
48474	Use 5023	-
4851	Rubber Wall Liner	9.14
4866	Obsolete	-
4870	Obsolete	-
4874	Obsolete	-
4875	Obsolete	-
4881	Obsolete	-
4888	H/I Stat.(replaces 6399)	34.41
48896	Clip x 4	6.92
48897	Cover (Not a spare)	0.68
48898	Main Printed Circuit Board	207.65
48899	Use 10024558	-
48900	Clip	2.92
48901	Hook	1.48
48902	Obsolete	-
48903	Seal	7.47
48904	Locking Nut	3.07
48905	Obsolete	-
48908	Use 5071	-
4891	Pilot Jet NG.27	0.84
48911	Use 6898	-
48914	Use 5070	-
48917	Use 8968	-
48918	Use 1947	-
48919	Clip	1.25
4892	Obsolete	-
48920	Use 1858	-
48921	Use 1864	-
48922	Cover	7.09
48923	Cover	9.03
48926	Use 10020217	-
48927	Use 1920	-
48928	Use 1549	-
48929	Use 5317	-
4893	Pilot Jet LPG.22	0.84
4897	Obsolete	-
4909	Obsolete	-
4910	Obsolete	-
4911	Obsolete	-
4916	Obsolete	-
4918	Obsolete	-
4923	Use 3434	-
4925	Obsolete	-
4930	Obsolete	-

SPARE PARTS

Part No.	Description	Price
4931	Pump Over - Run Thermostat	7.85
4932	Obsolete - Pilot Pipe	-
4934	Obsolete - Control Panel Hinge LH	-
4935	Obsolete - Control Panel Hinge RH	-
4936	Obsolete - Thermostat Knob	-
4937	Obsolete	-
4943	Obsolete	-
4944	Obsolete - Mounting Plate Back	-
4949	Obsolete	-
4961	Thermocouple	7.85
4962	Obsolete - Domestic Manifold	-
4965	Obsolete - Domestic Heat Exchanger Return Pipe	-
4975	Obsolete - Earth Terminal Tag	-
4976	Obsolete - Spacer for Thermostat	-
4977	Obsolete - Strip	-
4980	Obsolete - On/Off Switch	-
4981	Obsolete - Auto Summer/Winter Switch	-
4983	Obsolete - Heating switch	-
4994	Obsolete - Main Burner LPG	-
4998	Obsolete - Main Burner LPG	-
5023	3/4" Fibre Washer	0.37
5024	Obsolete - Fibre Washer	-
5025	Washer	0.79
5026	1/2" Fibre Washer	0.32
5027	Obsolete	-
5029	Obsolete	-
5036	Pump Washer	0.79
5038	Washer	0.37
5039	Washer	0.37
5040	Obsolete - Aluminium Washer	-
5041	Washer	0.16
5042	Washer	0.21
5048	Obsolete - Washer	-
5049	Gasket	0.47
5050	Obsolete - Screw	-
5052	Clip	0.26
5055	Obsolete	-
5067	Obsolete	-
5068	Seal	0.42
5070	Fibre Washer	0.26
5071	Fibre Washer	0.21
5072	Fibre Washer	0.53
5077	Screw	0.11
5078	Obsolete	-
5079	Screw	0.08
5080	Screw	0.16
5081	Screw	0.19
5082	Obsolete	-
5083	Screw	0.11
5084	Obsolete	-
5085	Obsolete	-
5086	Obsolete	-
5092	Obsolete	-
5093	Obsolete	-
5094	Obsolete	-
5095	Obsolete	-
5097	Obsolete	-
5105	Machine Screw M4 x 10mm	0.79
5111	Obsolete	-
5122	Obsolete	-
5124	Screw	0.26
5128	Edge Clip	0.16
5129	Obsolete - Screw	-
5131	Obsolete	-
5132	Obsolete - Hexagon Nut	-
5133	Obsolete - Washer	-
5134	Obsolete - Earth Connector	-
5136	Obsolete - Spacer	-
5140	Obsolete	-

SPARE PARTS

Part No.	Description	Price
5141	Obsolete	-
5142	Obsolete - Edge Clip	-
5143	Obsolete - Edge Clip	-
5150	Obsolete	-
5151	Edge Clip	0.15
5155	Obsolete - Cable Clip	-
5163	Obsolete	-
5166	Obsolete - Screw	-
5168	Rivet	0.05
5169	Obsolete - Self tapping screw	-
5170	Screw	0.37
5171	Obsolete - Screw	-
5172	Burner Plate	0.26
5174	Obsolete - Circlip	-
5175	Obsolete - Screw	-
5176	Screw	0.26
5178	Obsolete	-
5179	Obsolete - Circlip	-
5180	Obsolete - Screw	-
5182	Obsolete - Screw	-
5183	Machine Screw Hex Head M6 x 13	0.93
5184	Machine Screw Hex Head M4 x 12	0.79
5186	Obsolete - Screw	-
5187	Obsolete	-
5188	Obsolete - Screw	-
5192	Fibre Washer	0.32
5195	Fibre Washer	0.32
5197	Obsolete - Screw	-
5203	Plastic Washer	0.16
5207	Obsolete - Screw	-
5208	Washer	0.16
5209	Obsolete	-
5212	Obsolete	-
5213	Small Screw DHW Heat Exchanger	0.74
5214	Large Screw DHW Heat Exchanger	0.84
5216	Obsolete - Headless Screw	-
5219	Obsolete - Screw	-
5221	M5 Screw Phillips Hd	0.78
5224	Clip	0.63
5228	Obsolete	-
5230	Clip	0.42
5231	Obsolete	-
5235	Screw	0.58
5236	Washer	0.58
5237	Washer 28mm	0.74
5240	Obsolete - Screw	-
5251	Obsolete - Frame	-
5254	Obsolete - Door Panel	-
5255	Obsolete - Case Reinforcement R/H	-
5256	Obsolete - Case Reinforcement L/H	-
5258	Obsolete - Door Panel	-
5259	Obsolete - Control Panel Support Bracket (Left)	-
5261	Obsolete - Guard	-
5262	Temperature Gauge	14.78
5263	Pressure Gauge	18.11
5264	Obsolete - Thermostat Knob	-
5266	Obsolete - Back Panel Metal	-
5269	Front Insulation Panel for Combustion Chamber	6.45
5270	Rear Insulation Panel for Combustion Chamber	6.17
5271	Side Insulation Panel for Combustion Chamber	7.93
5275	Obsolete - Door Spring	-
5277	Obsolete - Air Separator and Return Pipe	-
5279	Gas valve support	1.95
5280	Pilot Assembly	12.22
5284	Obsolete - On/Off Switch	-
5295	Use 10020104	-
5296	Obsolete - Main Burner Town Gas	-
5297	Main Burner LPG	82.58
5298	Obsolete - Grommet	-

SPARE PARTS

Part No.	Description	Price
5299	Obsolete - Metal Side Panel R/H	-
5300	Metal Side Panel (L/H)	3.75
5301	Spindle	2.80
5303	Obsolete - Plastic Bush	-
5304	Plastic Bush	1.13
5305	Obsolete - Plastic Plate	-
5309	Spark electrode	6.64
5312	Back Side of Comb Chamber	6.34
5313	Obsolete - Combustion Chamber Front Cover	-
5315	Front Insulation Panel for Combustion Chamber	7.30
5316	Rear Insulation Panel for Combustion Chamber	6.90
5317	NG Burner (replaces 48929 and 10027564)	93.70
5318	Obsolete	-
5319	Main Burner LPG	95.50
5320	Obsolete - Air Separator and Return Pipe	-
5322	Screw M5X45	1.20
5323	Washer	0.32
5329	Obsolete - Cover for PCB	-
5332	Obsolete - Thermocouple	-
5333	Obsolete - Self Adhesive Tape	-
5335	Obsolete - Pipe	-
5351	Heat Exchanger	187.13
5356	Heat Exchanger	219.52
5366	Obsolete - Gas Valve Knob	-
5371	Obsolete - Cable Clamp	-
5388	Heat Exchanger with 2 x 5023 Washers	140.33
5394	Obsolete - Domestic Thermostat	-
5396	Obsolete - Wired Limit Thermostat	-
5436	Obsolete - Air Vent Bottle	-
5437	Obsolete - Plate	-
5438	Gas Valve	142.24
5441	High-limit Thermostat	6.25
5455	Obsolete - Socket Joint	-
5456	Obsolete - Connection	-
5470	Obsolete - Double Clamping Bracket	-
5472	Thermostat Clip	1.11
5475	Obsolete	-
550803	Aqua Flow Temp/Pressure Relief Valve	101.17
5588	Obsolete - Locating Stud	-
5589	Obsolete - Casing Lug	-
5591	Obsolete - Mode Selector Switch	-
5592	Mode Selector Switch	2.65
5602	Obsolete	-
5603	Obsolete	-
5604	Obsolete	-
5606	Obsolete	-
5617	Obsolete	-
5631	Obsolete	-
5634	Obsolete - Gas Valve	-
5635	Obsolete - Washer	-
5637	Use 0940	-
5638	Obsolete - 24/96 RSE Wiring Harness	-
5640	Spark Electrode & Lead	13.08
5641	Sensing Electrode & Lead	13.08
5643	Circuit Board	148.32
5731	Obsolete - Gas Pipe	-
5733	Obsolete - Pressure Switch	-
5735	Obsolete - Air Deflector	-
5739	Use 2076	-
5741	Obsolete - Fan Gasket	-
5742	Plate for gap between fan and Fan flue connector	1.66
5744	Obsolete - Air Tube Connecting Tee	-
5753	Use 10027352	-
5757	Obsolete - Control Knob	-
5758	Obsolete - Control Knob Extension	-
5776	Obsolete - Gas Connection	-
5784	Obsolete - Fixing Plate	-
5797	Circuit Board	-
5798	Obsolete - 20-80 Flowmatic Wiring Harness	136.00
5800	Piezo Ignitor	12.22

SPARE PARTS

Part No.	Description	Price
5808	Obsolete - Frame	-
5809	Obsolete - Case	-
5811	Obsolete - Control Panel Support	-
5812	Main Burner NG	47.50
5813	Obsolete - Main Burner LPG	-
5814	Obsolete	-
5852	Obsolete - Ignition Control Box	-
5853	Electrode & Lead	13.08
5863	Gas Valve Gasket	0.53
5868	Obsolete - Modulator Coil	-
5869	Obsolete - LPG Spring	-
5870	Obsolete	-
5876	Obsolete	-
5899	Obsolete - Expansion Vessel Pipe	-
5900	Obsolete - Seal	-
5901	Obsolete - Ignition Cable	-
5903	Use 7705	-
5904	Obsolete - Front Panel	-
5905	Combustion Chamber Seal (1 metre)	1.97
5906	Hood Assembly	29.35
5907	Hood Assembly	30.52
5908	Combustion Chamber Front (Metal)	8.06
5909	Combustion Chamber Front (Metal)	9.04
5910	Fan Assembly	88.90
5911	Fan Assembly	105.74
5912	Fan Gasket	10.56
5913	Flue Connection	7.43
5914	Obsolete - Flue Connection	-
5915	Obsolete - Tube	-
5916	Use 7315	-
5917	Use 7317	-
5921	Venturi	8.49
5922	Obsolete - Flange	-
5923	Obsolete - Air Deflector	-
5924	Obsolete - Air Baffle	-
5926	Pressure Switch	53.39
5927	Seal	3.78
5929	Pipe	13.29
5930	Pipe	14.01
5931	Obsolete - Pipe	-
5932	Obsolete - Pipe	-
5938	Obsolete - Pilot Pipe	-
5940	Obsolete	-
5944	Silicone Tube	1.74
5945	Obsolete	-
5948	Obsolete - Cover	-
5949	Air Baffle	1.69
5950	Obsolete - Air Baffle	-
5951	Obsolete - Air Baffle	-
5956	Obsolete - Side Panel	-
5957	Combustion Chamber Cover	15.02
5958	Hood Assembly	26.41
5960	Use 2819	-
5961	Combustion Chamber Front Panel	4.76
5962	Combustion Chamber Back Panel	4.76
5963	Fan Assembly	116.95
5964	Obsolete - Fan Seal	-
5965	Obsolete - Flue Connection	-
5966	Obsolete - Fan Union Tube	-
5967	Obsolete - Flow Pipe	-
5968	Obsolete - Pump Pipe	-
5969	Obsolete	-
5970	Obsolete - Pipe	-
5971	Silicon Tube	5.82
5972	Obsolete - Air Deflector	-
5973	Obsolete - Pipe Fixing Bracket	-
5974	Obsolete - Gas Pipe	-
6021	Motor Vehicles	8.97
6025	15/50 Excel complete pump Assembly	184.95
6026	Combustion Chamber Assembly	17.26

SPARE PARTS

Part No.	Description	Price
6027	Combustion Chamber	18.23
6028	Combustion Chamber	18.68
6151	Obsolete - Lead for Piezo	-
6160	Obsolete - Back Door Panel	-
6172	Obsolete	-
6173	Obsolete - Pipe for 3 Port Valve	-
6208	Obsolete - Half Inch Locknut	-
6228	Fan to Flue Connector (without Venturi's)	6.87
6266	Obsolete	-
6351	Obsolete	-
6352	Obsolete - Wiring Harness (Near full loom)	-
6354	Obsolete	-
6357	Obsolete - Gas Valve Manifold	-
6371	Obsolete - Flow Pipe	-
6373	Obsolete - Lint Guard	-
6374	Obsolete - Pilot Pipe	-
6375	Obsolete - Baffle Plate	-
6376	Obsolete - PCB	-
6377	Obsolete	-
6382	Obsolete - Flue Draft Divertor	-
6384	Obsolete - Flow Pipe	-
6385	Obsolete	-
6387	Obsolete - Main Burner NG	-
6388	Obsolete	-
6394	Obsolete - Front Panel	-
6395	Obsolete - Pilot Pipe	-
6396	Obsolete - Gas Valve Knob	-
6397	Obsolete - Main Burner	-
6398	Obsolete - Main PCB	-
6399	Use 4888	-
6400	Obsolete	-
6466	Reset Button	6.46
6471	Obsolete	-
6493	Resistor Replaced 4028	13.58
6494	Obsolete - Resistor	-
6495	Obsolete - Air Chamber	-
6516	Obsolete - Gas Valve	-
6614	High Limit Stat	7.43
6615	Obsolete - Thermostat Clip	-
6624	Obsolete - Bush for Pressure Sensor	-
6638	Obsolete - Delay Timer	-
666	Clip 24M	0.13
6676	Obsolete - Clock Blanking Plate	-
6678	Obsolete - Gas Valve	-
6679	Obsolete - Compensator NG	-
6681	Obsolete - PCB (Elidra)	-
6685	Obsolete - Aluminium Tube	-
6692	Obsolete - Aluminium Air Tube	-
6693	Obsolete - Thermostat Potentiometer Board	-
6694	Obsolete - Pressure Switch	-
6695	Obsolete - Aluminium Air Tube	-
6696	Obsolete - Air Tube Connecting Branch	-
6704	Obsolete - Pressure Sensor	-
6705	Obsolete - LED Board	-
6706	Obsolete - LED Cover	-
6759	Obsolete - Delay Timer	-
6781	Obsolete - Gas Valve to Burner Pipe	-
6785	Obsolete - Gas Valve Bracket	-
6802	Obsolete - Pipe	-
6814	Obsolete - Plastic Plate	-
6815	Obsolete	-
6817	Obsolete	-
6818	Obsolete	-
6851	Obsolete - Flow & Return Manifold	-
6853	Flow Manifold Cover	10.29
6854	Obsolete - Fulcrum Arm	-
6855	Nut (Rear of Flow Manifold)	7.65
6856	Obsolete - Tube Screw	-
6857	Safety Valve Sleeve	5.23
6858	Obsolete - By-Pass Seating	-

SPARE PARTS

Part No.	Description	Price
6859	Nut	2.42
6860	Front Seal	6.71
6862	Spring	2.55
6863	Use 8436	-
6864	Use 8437	-
6865	Spring	2.04
6866	Use 2910	-
6867	Bearer Plate	2.71
6868	Obsolete - Gasket	-
6870	Washer	1.11
6871	Use 8441	-
6872	Diaphragm	2.10
6873	Use 8435	-
6874	Screw	1.37
6876	Obsolete - Front Plate	-
6877	Obsolete - Locking Sleeve	-
6878	Obsolete - Blanking Plug	-
6879	Spring	0.79
6882	Diaphragm	4.99
6883	Bearer Plate	3.09
6884	Use 8438	-
6886	Venturi	4.85
6887	Push Rod	1.59
6888	Push Rod	1.27
6890	Push Rod	7.55
6891	Nut	15.70
6893	Use 1489	-
6894	O Ring	0.89
6895	O Ring	2.08
6896	Nut	8.37
6897	Pump Washer	0.63
6898	O Ring	0.89
6901	Use 01005043	-
6902	Obsolete	22.59
6903	Screw	1.33
6911	Obsolete - O-Ring	-
6912	Inlet Pipe	14.48
6913	Outlet Pipe	14.43
6914	Obsolete - Nipple	-
6919	Front Seal	4.16
6920	Obsolete - Spring for Gas Regulator	-
6921	Obsolete	-
6985	Venturi (Positive)	4.06
7022	Use 10027352	-
7068	Obsolete - Aluminium Tube	-
7070	Use 01005272	-
7071	Obsolete - Pressure Switch Cover	-
7076	Obsolete - Bar	-
7081	Obsolete - Gas Valve Elidra	-
7082	Obsolete - LED Board	-
7085	Obsolete - PCB (Elidra)	-
7094	Obsolete - Gas Connecting Barrel	-
7095	Obsolete - Main Burner	-
7096	Main Burner	103.62
7097	Ignition Control PCB	207.65
7098	Gas Cock	21.85
7099	Water Supply Stop Cock	14.27
7100	3/4" Flow/Return Valve 90 Deg	23.64
7126	Obsolete	-
7130	By-Pass Retaining Nut	2.81
7131	Domestic By-Pass	2.81
7132	Domestic Manifold Top	113.01
7133	Obsolete - Three Port Valve Front Cover	-
7134	Seating Plate	3.99
7135	O Ring	1.07
7139	Non Return Valve	6.45
7140	Domestic Heat Exchanger	146.25
7141	Domestic Heat Exchanger	158.10
7153	Obsolete - Main Burner LPG	-
7157	Obsolete - Instrument Panel	-

SPARE PARTS

Part No.	Description	Price
7159	Pressure Gauge	17.19
7160	Obsolete - Control Knob	-
7171	Use 4441	-
7172	Obsolete - Valve Cover Retaining Lug	-
7174	Obsolete	-
7175	Obsolete - Extension Bar	-
7192	Obsolete	-
7201	Obsolete - Frame	-
7204	Expansion vessel 8L	89.00
7206	Obsolete - Main Burner LPG	-
7207	Expansion Pipe	10.50
7209	Obsolete - Control Panel Support Bracket R/H	-
7210	Obsolete	-
7211	Obsolete - Front Panel	-
7212	Obsolete - Side Panel	-
7216	Obsolete - Connections Cover	-
7221	Pump Cable	7.33
7230	Obsolete - Gas Pipe	-
7232	Bridge	0.42
7233	Pipe	14.99
7236	NTC Sensor Rep 105922	8.45
7237	Obsolete - Instrument Panel	-
7238	Obsolete - Blanking Plug	-
7239	Pressure/Temp Gauge	31.29
7240	Obsolete - Control Knob	-
7243	LED Plug and Lead	11.87
7260	Gas Valve	163.86
7261	Obsolete	-
7266	Obsolete - Flow Pipe	-
7280	Fan to Flue Connector (Without Venturi's)	7.42
7281	Silicon Tube	2.37
7301	Obsolete	-
7303	Gas Control Knob	3.91
7304	Obsolete - Pilot Pipe	-
7311	Obsolete - High Limit Thermostat	-
7314	Obsolete - Pipe	-
7315	Clamp	1.37
7316	Clamp	2.80
7317	Washer	1.11
7318	Washer	1.52
7330	Gas cock	32.00
738	Clock Wires (Twin Channel)	-
7602	Obsolete - 80E/96E Wiring Harness	-
7615	Heat Exchanger. Return Pipe	14.32
7616	Obsolete - Excell Fittings Kit	-
7618	Use 5910	-
7619	Obsolete - Main Frame	-
7620	Expansion Vessel	86.53
7621	Heating Manifold	172.05
7622	Obsolete - Combustion Cover	-
7623	NG Burner	67.34
7624	Obsolete - LPG Burner	-
7625	Gas valve	172.05
7701	Obsolete - Side Panel	-
7705	Obsolete - Side Panel	-
7714	Obsolete - Gas Valve to Burner Pipe	-
7715	Obsolete	-
7723	Obsolete - Baffle	-
7724	Obsolete - Baffle	-
7725	Obsolete - Spark Electrode & Lead	-
7776	Obsolete - Gas Connecting Barrel	-
7777	Obsolete - Gas Valve to Burner Connector	-
7778	Obsolete - Sense Electrode	-
7779	Obsolete - Fan Outlet Connector	-
7780	Pump Cable	6.12
7781	Pipe	13.27
7782	Obsolete - Pump Return Tube	-
7783	Obsolete - Pipe	-
7784	Obsolete	-
7785	Obsolete - Control Panel Bracket	-

SPARE PARTS

Part No.	Description	Price
7786	Obsolete - Mounting Plate	-
7787	Obsolete - Bracket	-
7788	Obsolete - Bracket	-
7789	Obsolete - Thermostat Knob	-
7790	Obsolete - Clock Blanking Plate	-
7791	Ignition Box (Ineco)	141.27
7792	Obsolete - Logo Strip	-
7793	Obsolete - Case	-
7796	Obsolete - 14/48SE 20/70SE Wiring Harness	-
7804	Obsolete - Expansion Vessel	-
7805	Use 10020076	-
7806	Combustion Chamber	35.20
7808	NG burner	76.46
7809	NP 9 Main Burner LPG	93.63
7810	Heat Exchanger with 2 x 5023 Washers	160.61
7811	Use 2936	-
7812	Combustion Chamber Back Cover	5.74
7813	Combustion Chamber - Front	26.00
7814	Obsolete - R/H Fan Baffle	-
7815	L/H Fan Baffle	16.54
7816	Obsolete - Fan Outlet Connector	-
7817	Front Insulation Panel for Combustion Chamber	8.03
7818	Rear Insulation Panel for Combustion Chamber	7.35
7819	Obsolete - Pipe	-
7820	Obsolete - Pipe	-
7821	Obsolete - Logo Strip	-
7822	Combustion Chamber Front Panel	17.45
7824	Air box side	24.86
7831	Obsolete - Air Box Side	-
7832	Obsolete - Air Box Side	-
7835	Use 9763	-
7836	Obsolete - Pipe	-
7840	Obsolete - Gas Valve Bracket	-
7841	Obsolete - Mynute 28-96SE Wiring Harness	-
7842	Obsolete - Pump Wire	-
7843	Pipe	12.26
7844	Obsolete - Pipe	-
7845	Obsolete - Pipe	-
7846	Obsolete - Number Strip	-
7849	Air Chamber	42.07
7850	Obsolete - Pipe	-
7905	Obsolete - Gasket	-
7912	Obsolete - Gas Control Knob Extension	-
7915	Obsolete - Control Spindle Knob	-
7920	Obsolete - Casing	-
7948	Venturi Rep 6984 (Negative)	9.19
7999	O Ring	0.58
8008	Flow governor (White)	4.41
8009	Flow governor (Blue)	3.02
8030	Obsolete - Brass Sleeve	-
8031	Modulator coil	27.12
8036	Domestic Heat Exchanger (with 4 x 7999 O rings)	105.74
8037	Domestic Heat Exchanger	114.53
8076	Obsolete	-
8079	Obsolete - Pipe	-
8083	Fan Flue Tube	9.82
8084	Air Box Hole Cap	3.39
8085	Use 10026933	-
8086	Brass Cap	2.14
8088	Obsolete - Combustion Chamber	-
8094	Obsolete - Gas Valve Outlet	-
8098	Obsolete - Silicon Tube	-
8158	Room sealed chamber	50.39
8159	Obsolete - Gas Valve Bracket	-
8160	Obsolete - Gas Valve Connection	-
8161	Obsolete - Pilot Pipe	-
8162	Obsolete - Gas Control Knob Extension	-
8163	Obsolete - Pipe	-
8165	Obsolete - Logo Strip	-
8166	Main Printed Circuit Board	47.02

SPARE PARTS

Part No.	Description	Price
8167	Obsolete - Mynute 14-48SP Wiring Harness	-
8173	Circuit Board	172.05
8174	Obsolete - Excell 80SP Harness	-
8193	Obsolete - 80E/96E Wiring/new	-
8194	Obsolete - 80SP wiring, new	-
8195	Use 01005272	-
8196	Obsolete - Pressure Switch Plate	-
8199	Obsolete - Bracket	-
8200	Obsolete - 80E/96E Wiring	-
8214	Ignition Box (Brahma)	124.86
8221	Obsolete - Thermocouple	-
8277	Gas Valve	154.26
8282	Spark Electrode Inc Lead	12.18
8283	Obsolete - Spark Electrode	-
8301	Sensing Electrode with Lead	15.19
8306	Obsolete - Drip Cover	-
8308	Spark Electrode	15.15
8319	Obsolete - Pipe	-
8322	Obsolete - Guard	-
8344	Obsolete - Frame Assembly	-
8345	Gas Valve	220.36
8346	Obsolete - Instrument panel	-
8347	Obsolete	-
8348	Obsolete	-
8349	Obsolete - Adhesive film	-
8350	Obsolete	-
8353	Printed Circuit Board	92.01
8354	Obsolete - PCB Cover	-
8355	Pressure Gauge	14.06
8360	Ignition Box (9962)	167.81
8361	Obsolete - Screw	-
8364	Spark Electrode Inc Lead	13.08
8367	Use 2258	-
8377	Pressure Gauge	16.57
8378	Quick primer pressure gauge	13.13
8381	Obsolete - 3 Way Valve	-
8402	Obsolete - Silicone tube	-
8404	Obsolete - Control Panel	-
8428	Heating Manifold	89.00
8429	Domestic Manifold	45.93
8430	Heating Manifold Top	17.21
8431	Domestic Manifold Top	39.55
8432	Exchanger Connection	13.45
8433	Use 2907	-
8434	Venturi	2.80
8435	By-Pass Bobbin	1.19
8436	By-Pass Spring	1.62
8437	Spring	1.62
8438	Spring	1.41
8439	Plug	5.83
8440	Seating Plate	3.80
8441	Seating	3.91
8442	Fulcrum Arm	5.94
8444	O Ring	1.54
8445	Gasket	0.79
8446	Use 1489	-
8447	Use 01005177	-
8448	Screw	0.89
8460	Pipe	13.07
8465	Obsolete - Guard	-
8468	Use 01005177	-
8477	Obsolete - Tube	-
8478	Spark Electrode with Lead	14.18
8481	Printed Circuit Board	160.66
8484	Use 10027352	-
8528	Obsolete - Support Bracket	-
8529	Obsolete - Control Panel Bracket	-
8530	Obsolete - Control Panel Bracket	-
8533	Heating Distribution Manifold	207.65
8536	Domestic Water Manifold	77.13

SPARE PARTS

Part No.	Description	Price
8537	Connection	6.66
8538	Pressure Sensor Pipe	9.32
8539	Pressure Sensor Pipe	9.32
8540	Obsolete - Fixing Bracket	-
8541	Clip	0.63
8542	O Ring	0.63
8544	Obsolete - Gas Connection Pipe	-
8545	Obsolete - Pilot Pipe	-
8546	Obsolete - Gas Knob	-
8547	Combined High limit Flue Stat	23.55
8548	Expansion Vessel Pipe (Maxin)	9.65
8549	Flow Pipe	21.95
8550	Obsolete - Return Pipe	-
8558	Microswitch Clip	0.58
8559	Obsolete - Maxin Case	-
8584	Pipe	17.36
8585	Pipe	13.42
8589	Obsolete - Gas Pipe	-
8602	Use 1606	-
8607	Obsolete - Control Panel (rep by 1639)	-
8631	Obsolete	-
8633	Obsolete - Fulcrum Arm Nut	-
8634	Obsolete - Brass Rod for Fulcrum Arm	-
8635	Obsolete - Fulcrum Arm Locating	-
8654	Clock Blanking Plate	1.86
8673	Obsolete - Plastic Cover	-
8675	Flue Clamp and Gasket	5.24
8799	Obsolete - Wiring Harness 14-48	-
8809	Gauge	23.55
8852	Use 1191	-
8855	NTC Sensor	20.34
8860	Use 1194	-
8861	Obsolete - PCB Back Semi Box	-
8862	Obsolete - PCB Front Semi Box	-
8863	Obsolete	-
8864	Obsolete	-
8866	Brass Cap	1.05
8868	Pipe	20.63
8869	Obsolete	-
8871	Obsolete - Pipe	-
8872	Use 9731	-
8873	Fitting/union	6.01
8874	Use 9730	-
8876	Pump	175.79
8877	Obsolete - Pump Harness	-
8878	Use 1044	-
8880	Obsolete - Combustion Chamber	-
8881	Obsolete - Combustion Chamber Top	-
8882	Use 1035	-
8883	Obsolete - Silicone Seal	-
8884	Use 2810099	-
8885	Use 1033	-
8886	Obsolete - Burner Housing	-
8887	Use 1016	-
8888	Use 1193	-
8889	Use 1196	-
8890	Spreader Plate	19.60
8891	Use 10022853	-
8892	Use 1019	-
8893	Fan Gasket	4.97
8896	Gasket	0.58
8897	Obsolete - Main Burner Injector	-
8899	Use 9299	-
8900	Pilot Glass	2.63
8901	Obsolete - Glass Cover	-
8902	Washer	1.61
8903	Washer	0.85
8904	Sleeve	2.37
8906	Obsolete - Gas Pipe	-
8907	Obsolete - Gas Pipe	-

SPARE PARTS

Part No.	Description	Price
8908	Obsolete - Analyser test point	-
8909	Plug	2.85
8910	Non Return Valve	3.40
8911	Extension for AAV's (4254 + 9806)	4.00
8912	Washer	4.41
8913	Obsolete - Reducing Nipple	-
8914	Gasket	0.95
8915	Obsolete - Test Nipple	-
8916	Pressure Nipple	1.44
8918	Input P.C.B.	108.94
8921	Obsolete - Green-Red LED	-
8922	Obsolete	-
8951	Obsolete	-
8952	Obsolete - Connection	-
8953	Obsolete - Heating manifold	-
8954	Obsolete - Cover	-
8955	Pipe	33.11
8956	Pipe	9.78
8957	Obsolete - Pipe	-
8958	Connection Manifold	16.17
8959	O Ring	0.84
8960	Obsolete - Input PCB	-
8967	Obsolete - Silicone Tube	-
8968	Fuse (Individual) 2 AMP	0.68
8969	3.15 Amp fuse	0.68
8970	Main Burner Jet NG 3.8	4.90
8974	Obsolete - Gas Union Nipple	-
8975	Washer	2.37
9129	Obsolete - Main Burner Jet NG	-
9154	Obsolete - Silicone Tube	-
9156	Obsolete - Seal	-
9164	Use 7281	-
9232	Use 01005272	-
9233	Obsolete - Bracket	-
9263	Pump Lock Key	0.74
9264	Combustion chamber	15.07
9265	Obsolete - Back Frame	-
9266	Expansion Vessel - (8548 Pipe Needed If Old Vessel is Rectangle)	82.91
9268	Obsolete - Return Distribution Manifold	-
9269	Obsolete - Distribution Manifold	-
9270	Obsolete - Distribution Manifold	-
9271	Safety Valve Pipe	7.63
9272	Obsolete - Gas Valve Bracket	-
9273	Obsolete - Instrument Panel	-
9274	Obsolete - PCB Cover	-
9275	Obsolete - Guard	-
9285	Burner Washer	15.70
9286	Obsolete - Spacer	-
9287	Washer	6.85
9288	Spark Electrode	9.04
9289	Obsolete - O Ring	-
9291	Obsolete - Main Burner Jet Support	-
9292	Screw	6.49
9295	Main burner jet LPG	9.05
9296	Spring	0.63
9299	Washer	0.63
9430	Flow governor (Red)	3.02
9461	Selector Switch	3.78
9576	Obsolete - Gas Valve Bracket	-
9581	Use 0443/10SE 0444/14SE 0445	-
9582	Pressure Gauge	16.07
9583	Obsolete - Control Box top Panel	-
9586	Mynute 10, 14 & 20SE Harness	61.91
9587	Obsolete - Casing	-
9594	Pipe	25.20
9599	Knob	1.92
9695	Thermostat	6.64
9696	Obsolete - Limit Thermostat	-
9701	Front Panel	21.43
9709	Clock blanking plate	4.66

SPARE PARTS

Part No.	Description	Price
9716	Eclipse ESS Printed Circuit Board	398.87
9718	Flow governor (Black)	4.31
9730	Condense Connecting Nipple	9.48
9731	Condense Pipe replaced 8872	18.93
9732	Washer	0.74
9752	Cover	0.63
9753	Obsolete - Plastic Trade Mark label	-
9754	Obsolete - Air Chamber	-
9756	Expansion Vessel Pipe	10.48
9757	Obsolete - Pipe	-
9758	Pipe	19.70
9759	Knob	1.70
9761	Obsolete - Wiring Harness Maxim	-
9762	Obsolete - Valve Kit	-
9763	3/4" Flow/Return Valve Straight	26.37
9764	Water Stop Cock	21.40
9766	Connection	7.94
9771	Obsolete - Pump Cable	-
9772	Obsolete - Pipe	-
9773	Water Supply Stop Cock	25.81
9774	Mixing Valve	120.38
9786	Obsolete - Gas Connection Barrel	-
9794	Eclipse ESC Printed Circuit Board	398.87
9797	Gas Cock	20.85
9799	Obsolete - Frame	-
9800	Ignition Box	155.39
9805	Air Switch Bracket	1.05
9806	Auto Air Vent	9.60
9807	Fitting/union	15.20
9814	Obsolete - Guard	-
9842	Gas Valve	141.27
9849	Use 9806	-
9959	Use 1196	-
9960	Spark Electrode Cable	15.42
AE014	Obsolete	-
B81508	Case	-
B81510	Pressure Switch	145.95
B81511	Premix Burner	234.18
B81512	Detector	49.16
B81513	Pipe	77.30
B81514	Pipe	25.18
B81515	Use 105910	-
B81516	Replace Pipe 105910	17.38
B81517	Wiring Harness	59.04
B81518	Slave Wiring Harness	166.25
B81519	Master Wiring Harness	89.00
B81520	Serial Wiring	71.41
R103317	USE 10023566 (L) & 10023568 (S)	-
R103319	USE 10023569 (S) & 10023567 (L) OR 1786	-
S10002	Obsolete - Small Spring Gas Valve	-
S10003	Obsolete - Front Case R2A (S178	-
S10005	Obsolete - Large Spring Gas Valve	-
S10006	Obsolete - O Ring	-
S10007	Obsolete - Push Rod	-
S10008	Obsolete - Lower W-Section Nut	-
S10009	Obsolete - Washer	-

SPARE PARTS

Part No.	Description	Price
S10010	Obsolete - Burner Cover Plate	-
S10011	Obsolete - Test Nipple Union	-
S10012	Obsolete - Diaphragm	-
S10013	Use 10024364	-
S10014	Obsolete - Adjustment Spindle S	-
S10015	Obsolete - Washer	-
S10017	Obsolete - Spring	-
S10018	Obsolete - O Ring (Water Section)	-
S10019	Obsolete - Gland Nut	-
S10020	Obsolete - Upper water section	-
S10021	Obsolete - Electrode Lock Nut	-
S10023	Obsolete - Slow Ignition Device	-
S10024	Obsolete - Modulation Bobbin NG	-
S10025	Obsolete - Cold Water Inlet Pipe	-
S10026	Obsolete - Gas Valve Insert LPG	-
S10027	Obsolete - Hot Water Outlet Pipe	-
S10028	Obsolete - Modulation Bobbin LPG	-
S10029	Obsolete - Gas Valve Union Rear	-
S10030	Obsolete - Flow Tube	-
S10031	Obsolete - Venturi	-
S10032	Obsolete - Return Tube	-
S10033	Obsolete - Test Nipple Supply Pipe	-
S10034	Obsolete - Filter	-
S10035	Obsolete - Pilot tube	-
S10036	Obsolete - Gas Valve Union	-
S10037	Obsolete - Microswitch Bracket	-
S10038	Obsolete - Burner Injector NG	-
S10040	Obsolete - Burner Injector LPG	-
S10041	Obsolete - Temp Regulating Spin	-
S10042	Obsolete - Sleeve Nut	-
S10048	Obsolete - Mech Gas Assembly	-
S10049	Obsolete - M Switch Adj Lever	-
S10050	Obsolete - Microswitch	-
S10055	Obsolete - Electronic Ignition	-
S10057	Obsolete - Rear Outer Case	-
S10061	Obsolete - Extension Screw	-
S10063	Use 5911	-
S10064	Use 10023699	-
S10069	Obsolete - Hood Assembly	-
S10070	Obsolete - Comb Chamber Cover	-
S10071	Obsolete - Silicon Tube	-
S10082	Obsolete - Washer	-
S10083	Obsolete - Screw	-
S10084	Obsolete	-
S10086	Obsolete - Sight Glass Outer	-
S10087	Obsolete - Sight Glass Outer	-
S10088	Obsolete - Sight Glass Inner	-
S10089	Obsolete - Sight Glass Retainer	-
S10090	Obsolete - Wiring Harness	-
S10091	Obsolete - Washer	-
S10092	Obsolete - Connecting Leads	-
S10093	Obsolete - Washer for Modulation	-
S10095	Obsolete - Test Nipple Union	-
S10096	Use S10098	-
S10097	Obsolete - Mech Gas Ass Upper	-
S10098	Obsolete - Outer Case Seal Top & Bottom	-

*No discount available on these items.

All prices exclude VAT and delivery.
Prices quoted in sterling for UK only.

SPARE PARTS

Part No.	Description	Price
S10099	Obsolete - Gas Valve Gasket	-
S10106	Obsolete - Pilot Tube Olive	-
S10108	Obsolete - Microswitch	-
S10111	Obsolete - Heat Exchanger Pipe Clamp	-
S10113	Obsolete - On/Off Switch	-
S10114	Obsolete - Screw	-
S10115	Obsolete - Heat Exchanger	-
S10116	Obsolete - Main Burner	-
S10118	Obsolete - Water section	-
S10119	Obsolete - Reset Button Switch	-
S10123	Obsolete - Control knob	-
S10124	Obsolete - Temperature Control	-
S10129	Obsolete - Spark electrode	-
S10131	Obsolete - Fibre Washer	-
S10132	Obsolete - Pilot Assembly	-
S10133	Obsolete - Gas Valve	-
S10134	Obsolete - Pilot Injector (NG)	-
S10135	Obsolete - Pilot Injector LPG	-
S10137	Obsolete - Spark Electrode	-
S10140	Obsolete - Spring Case Fastners	-
S10144	Obsolete Electrode lead	-
S10145	Use S10144	-
S10148	Not available Complete	-
S10149	Use 10021235	-
S10153	Obsolete - Gas Inlet Pipe	-
S10154	Obsolete - Test Nipple Supply Pipe	-
S10160	Obsolete - Pilot Tube Union	-
S10164	Obsolete - Spring	-
S10166	Obsolete - Test Nipple Screw	-
S10167	Obsolete - Gas Valve	-
S10168	Obsolete - Ignition Control Box	-
S10169	Obsolete - Pipe	-
S10170	Obsolete - Pilot Tube	-
S10171	Obsolete - Pilot Assembly	-
S10172	Obsolete - NG Injector	-
S10173	Obsolete - LPG Injector	-
S10174	Obsolete - Electrode	-
S10176	Obsolete - Lockout Indicator	-
S10177	Obsolete - Hot Water Outlet Pipe	-
S10178	Obsolete - Mechanical Gas Valve	-
S10179	Obsolete - Mechanical Gas Valve	-
S10180	Obsolete - Gas Valve Union (Rear)	-
S10181	Obsolete - Gas Inlet Pipe	-
S10182	Obsolete - Test Nipple Supply Pipe	-
S10183	Use S10118	-
S10184	Obsolete - Spindle	-
S10185	Obsolete - Screw M4 x 50	-
S10186	Obsolete - Screw M4 x 25	-
S10187	Obsolete - Gas Body	-
S10188	Obsolete	-
S10189	Obsolete - Venturi	-
S10190	Obsolete - Venturi	-
S150	AquaNova hanging bracket	6.00
S152	Knob	7.73
S159	Valve	100.85
S190	Awaiting description	58.23

SPARE PARTS

Part No.	Description	Price
S209	Awaiting description	10.10
S419	Obsolete - Fan Exh Pipe	48.02
S432	Lateral Insulating Panel	5.66
S433	Front Insulating Panel	5.66
S435	Rear Insulating Panel	5.66
S438	Proof Chamber Cover (W7050168)	23.78
S474	Proof Chamber Cover	29.63
S538	Sensing Electrode	16.94
S597	Spring	1.16
S606	Frame (W7050335)	24.50
S612	Sight glass Kit	7.56
S656	Burner (without diffuser)	111.54
S659	Obsolete - NG Diffuser for Burner	-
S660	LPG Diffuser (for Burner)	32.94
S663	Hood Assembly	37.65
S675	Sensing Electrode (W7080195)	28.23
S757	Adaptor Ring	2.84
S758	Fan	98.82
T0001	Service Kit	45.49
T0002	3 Port Valve Service Kit	43.90
T0019	Excell Service Kit	31.90
T0021	Obsolete	-
T0023	Obsolete	-
T0024	Obsolete	-
T0026	Obsolete	-
T0027	Obsolete	-
T0029	Obsolete - AO Pump Back Section	-
T0030	Obsolete - Suppressor Pre 1994	-
T0031	Obsolete - Suppressor	-
T0034	Obsolete	-
T0035	Obsolete	-
T0041	Blanking Kit	4.91
T0042	Obsolete - 17mm Alan Keys	-
T0043	Obsolete - 12mm Alan Keys	-
T0044	Obsolete - 4mm Alan Keys	-
T0045	Obsolete - 22mm Alan Key	-
T0052	Venturi Extractor	9.98
T0053	Obsolete - 5mm Alan Key	-
T0055	Obsolete	-
T0058	Maxin Service Kit	43.50
T0063	Linea Service Kit	32.03
T0078	Use 1859	-
T0079	Use 1860	-
T0090	Linea 7/Syntesi service Kit	22.69
T0091	Obsolete - Carbon monoxide detector	-
T0092	Obsolete - Sentinel X100 Rapid Dose Inhibitor & Water Test Kit	-
W7060407	Use S150	-
No Discount on the below		
6090	Pump 25-50	96.06
6110	Pump 25-60	70.75
T0028	Wind Modification Kit	20.94
T0046	Gas valve adjustment tool	12.76
T0051	Motorised Valve	26.12



Domestic
Gas Boilers



Commercial
Gas Boilers



Solar Thermal



Heat Pumps



Water Heating



Smart
Controls



Spares &
Accessories



Service

Registered address:

Vokèra Limited
Borderlake House
Unit 7 Riverside Industrial Estate
London Colney
Herts AL2 1HG

enquiries@vokera.co.uk
www.vokera.co.uk

Sales, General Enquiries:
T 0844 391 0999
F 0844 391 0998

Vokèra Ireland
Westcourt Business Park
Callan
Kilkenny
R95 PW40

www.vokera.ie

T 056 775 5055
F 056 775 5060



© 2017 Vokèra Limited.
We reserve the right to change specification without prior notice.
Consumers statutory rights are not affected.
All rights reserved. E&OE.

A Riello Group Company. Company Reg No: 1047779

Issue 01/17/BW