

Quick Start Help Guide

OpenTherm 711 Quick Start Guide

Setting the time of day and day of the week

Press the  button then the  button. Wait until the symbols start flashing, then press the  again. Use the  and  buttons to set the hour. Press the  button again to begin setting the minutes, use the  and  buttons to set the minutes, press the  to exit.

Press the  button then the  button twice. The house symbol will now appear, when the symbols start flashing, press the  button again and use the  and  buttons to set the day. When set press the  button to exit.

Setting the temperatures

Press the  button twice, when the comfort temperature flashes, use the  and  buttons to set the desired temperature. To set the economy temperature (*the minimum temperature you want the house to be*) press the  button in this mode, use the  and  buttons to set, then press the  button to exit.

Setting the 'on' and 'off' times

Press the  button once, then press the  button three times. Once the black bars start flashing, press the  button again. Press the  button until the display shows your desired time. By pressing the  button, you can choose whether you wish to set the economy temperature (*bottom black bars*), the comfort setting (*top black bars*) or the OFF setting (*no black bars*). Pressing the  button will repeat the settings for each hour or 30 minute segment. Press the  button to proceed to the next day.

How to over-ride the settings

Pressing the  button will advance the settings. The 'party mode' symbol , will put the boiler on immediately and stay on indefinitely (*on first version, it will revert to original settings at midnight*). The 'holiday mode' symbol , will put the boiler in 'holiday mode' and will only operate at the economy temperature setting. If no symbols are displayed on the left, only the hot water will function.

The wifi symbol shows that communication is established and the heating is working from the programmed settings.